

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS

Acerbi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers	Wabco Trailer EBS

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Adamoli

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



















Adige

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




Astra

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 HD7-C 42.36	ENGINE MANAGEME	Cursor 13 F3BE0681JB	BOSCH EDC MS 6.2
 HD7-C 42.40	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 42.45	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 64.36	ENGINE MANAGEME	Cursor 13 F3BE0681JB	BOSCH EDC MS 6.2
 HD7-C 64.40	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 64.45	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 64.50	ENGINE MANAGEME	Cursor 13 F3BE0681FB	BOSCH EDC MS 6.2
 HD7-C 66.36	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 66.36	ENGINE MANAGEME	Cursor 13 F3BE0681FB	BOSCH EDC MS 6.2
 HD7-C 66.36	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 66.36	ENGINE MANAGEME	Cursor 13 F3BE0681JB	BOSCH EDC MS 6.2
 HD7-C 84.36	ENGINE MANAGEME	Cursor 13 F3BE0681JB	BOSCH EDC MS 6.2
 HD7-C 84.40	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 84.45	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 84.50	ENGINE MANAGEME	Cursor 13 F3BE0681FB	BOSCH EDC MS 6.2
 HD7-C 86.40	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 86.45	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 86.50	ENGINE MANAGEME	Cursor 13 F3BE0681FB	BOSCH EDC MS 6.2

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




Atlas

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




Bartoletti

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS

Berger

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Bertoja

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Broshuis

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS + TRACT. CONT	Trailers	Wabco Trailer VCS
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Cardi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




Carmosino

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS + TRACT. CONT	Trailers	Wabco Trailer VCS
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Chiavetta

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS






























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2	ABS + TRACT. CONT	1.4	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	1.6 16v	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	1.9 D	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	2.0 16v	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI 16v	BOSCH ABS/ESP 5.7
 Berlingo 2	ENGINE MANAGEME	1.4 KFW	SAGEM S2000
 Berlingo 2	ENGINE MANAGEME	1.6 16v NFU	BOSCH Motronic ME7.4.4
 Berlingo 2	ENGINE MANAGEME	2.0 HDI RHT	BOSCH EDC 15 C2 Common Rail
 Berlingo 2	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS Diesel SID 801
 Berlingo 2	RADIO / CD	1.4	CLARION
 Berlingo 2	RADIO / CD	1.4	PHILIPS
 Berlingo 2	RADIO / CD	1.4	VDO
 Berlingo 2	RADIO / CD	1.6 16v	CLARION
 Berlingo 2	RADIO / CD	1.6 16v	PHILIPS
 Berlingo 2	RADIO / CD	1.6 16v	VDO
 Berlingo 2	RADIO / CD	1.9 D	CLARION
 Berlingo 2	RADIO / CD	1.9 D	PHILIPS
 Berlingo 2	RADIO / CD	1.9 D	VDO
 Berlingo 2	RADIO / CD	2.0 16v	CLARION
 Berlingo 2	RADIO / CD	2.0 16v	PHILIPS
 Berlingo 2	RADIO / CD	2.0 16v	VDO
 Berlingo 2	RADIO / CD	2.0 HDI	CLARION
 Berlingo 2	RADIO / CD	2.0 HDI	PHILIPS
 Berlingo 2	RADIO / CD	2.0 HDI	VDO
 Berlingo 2	RADIO / CD	2.0 HDI 16v	CLARION
 Berlingo 2	RADIO / CD	2.0 HDI 16v	PHILIPS
 Berlingo 2	RADIO / CD	2.0 HDI 16v	VDO
 Berlingo 2	VISUAL./TELEMATICS	1.4	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	1.6 16v	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	1.9 D	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	2.0 16v	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	2.0 HDI 16v	SAGEM JCAE
 Berlingo	ABS	1.1 HDY	BOSCH ABS ABR 5.3
 Berlingo	ABS	1.1 HDZ	BOSCH ABS ABR 5.3
 Berlingo	ABS	1.4 KFX	BOSCH ABS ABR 5.3
 Berlingo	ABS	1.9 D WJY	BOSCH ABS ABR 5.3
 Berlingo	ABS	2.0 HDI RHY	BOSCH ABS ABR 5.3
 Berlingo	AIRBAG	1.1 HDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	1.1 HDZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	1.4 KFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	1.9 D WJY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	2.0 HDI RHY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	CHASSIS NETWORK	1.1 (...01)	VALEO Body Computer
 Berlingo	CHASSIS NETWORK	1.4 (...01)	VALEO Body Computer
 Berlingo	CHASSIS NETWORK	1.9 D (...01)	VALEO Body Computer
 Berlingo	CHASSIS NETWORK	2.0 HDI (...01)	VALEO Body Computer
 Berlingo	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Berlingo	ENGINE MANAGEME	1.1 HDY	BOSCH MonoMotronic MA3.1
 Berlingo	ENGINE MANAGEME	1.1 HDZ	BOSCH MonoMotronic MA3.1
 Berlingo	ENGINE MANAGEME	1.4 KFX	MARELLI MM 1AP.40
 Berlingo	ENGINE MANAGEME	1.4 KFX	SAGEM SL 96
 Berlingo	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS Diesel SID 801
 Berlingo	ENGINE MANAGEME	2.0 HDI RHY (...00)	BOSCH EDC 15 C2 Common Rail
 Berlingo	KEY ENCODE	1.1	Valeo/Siemens
 Berlingo	KEY ENCODE	1.4	Valeo/Siemens
 Berlingo	KEY ENCODE	1.9 D	Valeo/Siemens
 Berlingo	KEY ENCODE	2.0 HDI	Valeo/Siemens

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo	RADIO / CD	1.1	CLARION
 Berlingo	RADIO / CD	1.1	PHILIPS
 Berlingo	RADIO / CD	1.1	VDO
 Berlingo	RADIO / CD	1.4	CLARION
 Berlingo	RADIO / CD	1.4	PHILIPS
 Berlingo	RADIO / CD	1.4	VDO
 Berlingo	RADIO / CD	1.9 D	CLARION
 Berlingo	RADIO / CD	1.9 D	PHILIPS
 Berlingo	RADIO / CD	1.9 D	VDO
 Berlingo	RADIO / CD	2.0 HDI	CLARION
 Berlingo	RADIO / CD	2.0 HDI	PHILIPS
 Berlingo	RADIO / CD	2.0 HDI	VDO
 Berlingo	SERVICE LIGHT RES	1.1 (98-00)	Sagem
 C15	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 C15	ELECTRONIC INJECTI	1.1 HDZ	BOSCH MonoJetronic A2.2 [Slow]
 C15	ELECTRONIC INJECTI	1.4 KDY	BOSCH MonoJetronic A2.2 [Slow]
 Jumper 2	ABS	2.0 16v	BOSCH ABS ABR 5.3
 Jumper 2	ABS	2.8	BOSCH ABS ABR 5.3
 Jumper	ABS		BOSCH ABS ABR 5.3
 Jumpy 2	DIESEL ADDITION	2.0 JTD FAP	MARVAL
 Jumpy 2	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Jumpy 2	ENGINE MANAGEME	2.0 HDI RHZ (..-00)	BOSCH EDC 15 C2 Common Rail
 Jumpy	ABS	1.9 D WJY	BOSCH ABS ABR 5.3
 Jumpy	ABS	1.9 TD DHX	BOSCH ABS ABR 5.3
 Jumpy	ABS	2.0 HDI RHY	BOSCH ABS ABR 5.3
 Jumpy	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Jumpy	DIESEL MANAGEMEN	1.9 TD DHX	BOSCH AS3 VP20
 Jumpy	ENGINE MANAGEME	2.0 HDI RHT	BOSCH EDC 15 C2 Common Rail
 Jumpy	ENGINE MANAGEME	2.0 HDI RHY (..-00)	BOSCH EDC 15 C2 Common Rail

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS











































CTC

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS

DAF

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 CF 65	BRAKE SYS. MANAGE	CF 65.180 (02-..)	WABCO EBS EURO
 CF 65	BRAKE SYS. MANAGE	CF 65.220 (02-..)	WABCO EBS EURO
 CF 65	BRAKE SYS. MANAGE	CF 65.250 (02-..)	WABCO EBS EURO
 CF 65	SUSPENSION CONTR	CF 65.180 (02-..)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	CF 65.180 (02-..)	WABCO ECAS JED
 CF 65	SUSPENSION CONTR	CF 65.220 (02-..)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	CF 65.220 (02-..)	WABCO ECAS JED
 CF 65	SUSPENSION CONTR	CF 65.250 (02-..)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	CF 65.250 (02-..)	WABCO ECAS JED
 CF 75	BRAKE SYS. MANAGE	CF 75.250 (02-..)	WABCO EBS EURO
 CF 75	BRAKE SYS. MANAGE	CF 75.310 (02-..)	WABCO EBS EURO
 CF 75	BRAKE SYS. MANAGE	CF 75.360 (02-..)	WABCO EBS EURO
 CF 75	SUSPENSION CONTR	CF 75.250 (02-..)	WABCO ECAS 3
 CF 75	SUSPENSION CONTR	CF 75.250 (02-..)	WABCO ECAS JED
 CF 75	SUSPENSION CONTR	CF 75.310 (02-..)	WABCO ECAS 3
 CF 75	SUSPENSION CONTR	CF 75.310 (02-..)	WABCO ECAS JED
 CF 75	SUSPENSION CONTR	CF 75.360 (02-..)	WABCO ECAS 3
 CF 75	SUSPENSION CONTR	CF 75.360 (02-..)	WABCO ECAS JED
 CF 85	BRAKE SYS. MANAGE	CF 85.340 (02-..)	WABCO EBS EURO
 CF 85	BRAKE SYS. MANAGE	CF 85.380 (02-..)	WABCO EBS EURO
 CF 85	BRAKE SYS. MANAGE	CF 85.430 (02-..)	WABCO EBS EURO
 CF 85	BRAKE SYS. MANAGE	CF 85.480 (02-..)	WABCO EBS EURO
 CF 85	SUSPENSION CONTR	CF 85.340 (02-..)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	CF 85.340 (02-..)	WABCO ECAS JED
 CF 85	SUSPENSION CONTR	CF 85.380 (02-..)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	CF 85.380 (02-..)	WABCO ECAS JED
 CF 85	SUSPENSION CONTR	CF 85.430 (02-..)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	CF 85.430 (02-..)	WABCO ECAS JED
 CF 85	SUSPENSION CONTR	CF 85.480 (02-..)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	CF 85.480 (02-..)	WABCO ECAS JED
 XF 95	BRAKE SYS. MANAGE	XE 280 C (02-..)	WABCO EBS EURO
 XF 95	BRAKE SYS. MANAGE	XE 315 C (02-..)	WABCO EBS EURO
 XF 95	BRAKE SYS. MANAGE	XE 355 C (02-..)	WABCO EBS EURO
 XF 95	BRAKE SYS. MANAGE	XE 390 C (02-..)	WABCO EBS EURO
 XF 95	SUSPENSION CONTR	XE 280 C (02-..)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 280 C (02-..)	WABCO ECAS JED
 XF 95	SUSPENSION CONTR	XE 315 C (02-..)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 315 C (02-..)	WABCO ECAS JED
 XF 95	SUSPENSION CONTR	XE 355 C (02-..)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 355 C (02-..)	WABCO ECAS JED
 XF 95	SUSPENSION CONTR	XE 390 C (02-..)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 390 C (02-..)	WABCO ECAS JED

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





De Angelis

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




Doll

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS + TRACT. CONT	Trailers	Wabco Trailer VCS
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS










D-TEC

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




EvoBus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TRAVEGO	BRAKE SYS. MANAGE	O 580 15 RH	BS EBS ZF
 TRAVEGO	BRAKE SYS. MANAGE	O 580 15 RHD	BS EBS ZF
 TRAVEGO	BRAKE SYS. MANAGE	O 580 17 RHD	BS EBS ZF
 TRAVEGO	CRUISE CONTROL	O 580 15 RH	FR FMR
 TRAVEGO	CRUISE CONTROL	O 580 15 RHD	FR FMR
 TRAVEGO	CRUISE CONTROL	O 580 17 RHD	FR FMR
 TRAVEGO	ENGINE MANAGEME	O 580 15 RH	MR PLD
 TRAVEGO	ENGINE MANAGEME	O 580 15 RHD	MR PLD
 TRAVEGO	ENGINE MANAGEME	O 580 17 RHD	MR PLD

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Feldbinder

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS

















































Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo'	ABS	1.2 16v	ATE TEVES ABS Mk20
 Doblo'	ABS	1.2 8v	ATE TEVES ABS Mk20
 Doblo'	ABS	1.9 D	ATE TEVES ABS Mk20
 Doblo'	ABS	1.9 JTD	ATE TEVES ABS Mk20
 Doblo'	ABS	80 1.9 JTD	ATE TEVES ABS Mk20
 Doblo'	AIRBAG		AUTOLIV AirBag MY 99 (1F-2P)
 Doblo'	AIRBAG		AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo'	AIRBAG		AUTOLIV AirBag MY 99 (2F-2P-I)
 Doblo'	AIRBAG		SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo'	AIRBAG		SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo'	AIRBAG		SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo'	CHASSIS NETWORK	1.2 16v	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.2 16v	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.2 16v	Fiat Proxi Alignment
 Doblo'	CHASSIS NETWORK	1.2 8v	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.2 8v	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.2 8v	Fiat Proxi Alignment
 Doblo'	CHASSIS NETWORK	1.2 8v (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.2 8v (03-..)	Fiat Proxi Alignment
 Doblo'	CHASSIS NETWORK	1.2 8v Bipower (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.2 8v Bipower (03-..)	Fiat Proxi Alignment
 Doblo'	CHASSIS NETWORK	1.3 Multijet (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.3 Multijet (03-..)	Fiat Proxi Alignment
 Doblo'	CHASSIS NETWORK	1.6 16v (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.6 16v (03-..)	Fiat Proxi Alignment
 Doblo'	CHASSIS NETWORK	1.9 D	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.9 D	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.9 D	Fiat Proxi Alignment
 Doblo'	CHASSIS NETWORK	1.9 DS (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.9 DS (03-..)	Fiat Proxi Alignment
 Doblo'	CHASSIS NETWORK	1.9 JTD	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.9 JTD	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.9 JTD	Fiat Proxi Alignment
 Doblo'	CHASSIS NETWORK	1.9 JTD (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.9 JTD (03-..)	Fiat Proxi Alignment
 Doblo'	DASHBOARD	1.2 16v	VEGLIA/MARELLI
 Doblo'	DASHBOARD	1.2 8v	VEGLIA/MARELLI
 Doblo'	DASHBOARD	1.9 D	VEGLIA/MARELLI
 Doblo'	DASHBOARD	1.9 JTD	VEGLIA/MARELLI
 Doblo'	DIESEL MANAGEMEN	1.9 D	LUCAS EPIC DCU3F
 Doblo'	ENGINE MANAGEME	1.2 (01-..)	EOBD
 Doblo'	ENGINE MANAGEME	1.2 8v	MARELLI IAW 49F/59F EOBD
 Doblo'	ENGINE MANAGEME	1.2 8v	MARELLI IAW 59F
 Doblo'	ENGINE MANAGEME	1.2 8v	MARELLI IAW 5AF
 Doblo'	ENGINE MANAGEME	1.3 Multijet	MARELLI 6JF CF3
 Doblo'	ENGINE MANAGEME	100 1.9 JTD (02-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Doblo'	ENGINE MANAGEME	80 1.9 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Doblo'	KEY ENCODE	1.2 16v	DELPHI/MARELLI CODE Body Computer
 Doblo'	KEY ENCODE	1.2 8v	DELPHI/MARELLI CODE Body Computer
 Doblo'	KEY ENCODE	1.9 D	DELPHI/MARELLI CODE Body Computer
 Doblo'	KEY ENCODE	1.9 JTD	DELPHI/MARELLI CODE Body Computer
 Ducato Nuovo	ABS	2.8 JTD	BOSCH ABS 5.3
 Ducato Nuovo	ABS	2.8 JTD (03-..)	BOSCH ABS 5.3
 Ducato Nuovo	AIRBAG		SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato Nuovo	AIRBAG		SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato Nuovo	AIRBAG		SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato Nuovo	AIRBAG	(03-..)	SIEMENS AirBag MY 99 (1F-2P)
 Ducato Nuovo	AIRBAG	(03-..)	SIEMENS AirBag MY 99 (1F-3P)

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ducato Nuovo	AIRBAG	(03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato Nuovo	AIRBAG	(03-..)	SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato Nuovo	AIRBAG	(03-..)	SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato Nuovo	ENGINE MANAGEME	2.8 JTD (03-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato Nuovo	IMMOBILIZER	2.8 JTD	DELPHI CODE 2
 Ducato Nuovo	IMMOBILIZER	2.8 JTD (03-..)	DELPHI CODE 2
 Ducato Nuovo	SERVICE LIGHT RES	(03-..)	
 Ducato Restyling	ABS	2.0 (98-..)	BOSCH ABS 5.3
 Ducato Restyling	ABS	2.0 JTD (98-..)	BOSCH ABS 5.3
 Ducato Restyling	ABS	2.3 JTD (98-..)	BOSCH ABS 5.3
 Ducato Restyling	ABS	2.8 JTD (98-..)	BOSCH ABS 5.3
 Ducato Restyling	ABS	Bipower-Gpower (98-..)	BOSCH ABS 5.3
 Ducato Restyling	AIRBAG		SIEMENS AirBag MY 99 (1F-2P)
 Ducato Restyling	AIRBAG		SIEMENS AirBag MY 99 (1F-3P)
 Ducato Restyling	AIRBAG		SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato Restyling	AIRBAG		SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato Restyling	AIRBAG		SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato Restyling	CENTRAL LOCKING	2.0	RF Bloccaporte/ricevitore VAS 97/3
 Ducato Restyling	CENTRAL LOCKING	2.0 JTD	RF Bloccaporte/ricevitore VAS 97/3
 Ducato Restyling	CENTRAL LOCKING	2.3 JTD	RF Bloccaporte/ricevitore VAS 97/3
 Ducato Restyling	CENTRAL LOCKING	2.8 JTD	RF Bloccaporte/ricevitore VAS 97/3
 Ducato Restyling	CENTRAL LOCKING	Bipower-Gpower	RF Bloccaporte/ricevitore VAS 97/3
 Ducato Restyling	ENGINE MANAGEME	2.0 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato Restyling	ENGINE MANAGEME	2.3 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato Restyling	ENGINE MANAGEME	2.8 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato Restyling	IMMOBILIZER	2.0	DELPHI CODE 2
 Ducato Restyling	IMMOBILIZER	2.0 JTD	DELPHI CODE 2
 Ducato Restyling	IMMOBILIZER	2.3 JTD	DELPHI CODE 2
 Ducato Restyling	IMMOBILIZER	2.8 JTD	DELPHI CODE 2
 Ducato Restyling	IMMOBILIZER	Bipower-Gpower	DELPHI CODE 2
 Ducato Restyling	SERVICE LIGHT RES	2.0	
 Ducato Restyling	SERVICE LIGHT RES	2.0 JTD	
 Ducato Restyling	SERVICE LIGHT RES	2.3 JTD	
 Ducato Restyling	SERVICE LIGHT RES	2.8 JTD	
 Ducato Restyling	SERVICE LIGHT RES	Bipower-Gpower	
 Ducato	ABS		BOSCH ABS 5.3
 Ducato	AIRBAG		BREED AirBag + Pret.
 Ducato	AIRBAG		BREED AirBag MY 97 (1F-2P)
 Fiorino	ELECTRONIC INJECTI	1.5 AT Kat	BOSCH MonoJetronic A2.2
 Fiorino	ELECTRONIC INJECTI	1.5 Kat	BOSCH MonoJetronic A2.2
 Fiorino	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Scudo	ABS		BOSCH ABS ABR 5.3
 Scudo	DIESEL MANAGEMEN	1.9 D WJY (00-..)	LUCAS Diesel DCN2
 Scudo	DIESEL MANAGEMEN	1.9 TD	BOSCH AS3 VP20
 Scudo	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Scudo	ENGINE MANAGEME	2.0 JTD (.-99)	BOSCH EDC 15 C2 Common Rail
 Scudo	ENGINE MANAGEME	2.0 JTD RHT	BOSCH EDC 15 C2 Common Rail
 Strada	DIESEL MANAGEMEN	1.9 D (99-..)	LUCAS EPIC DCU3F

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS















Fliegl

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS


Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Courier	ENGINE MANAGEME	1.3 J4C (95-..)	FORD SEFI EEC-V
 Courier	ENGINE MANAGEME	1.3 J6B (..-96)	FORD EFI EEC-IV
 Courier	ENGINE MANAGEME	1.4 FHA (95-..)	FORD SEFI EEC-V
 Tourneo	ENGINE MANAGEME	2.0 NGS (94-..)	FORD SEFI EEC-V
 Tourneo	ENGINE MANAGEME	2.0 NSF (94-..)	FORD SEFI EEC-V
 Transit	ABS		BOSCH ABS 5
 Transit	AIRBAG	(..-00)	FORD AirBag SRS
 Transit	AIRBAG	(..-01)	FORD AirBag SRS
 Transit	ENGINE MANAGEME	2.0 (97-..)	FORD SEFI EEC-V
 Transit	ENGINE MANAGEME	2.4 TD Di DOFA (..-01)	FORD Diesel - Duratorq-Di EEC-V
 Transit	ENGINE MANAGEME	2.5 TD (97-..)	FORD Diesel EEC-V
 Transit	KEY ENCODE	(..-00)	FORD PATS
 Transit	KEY ENCODE	(95-99)	FORD PATS
 Transit	SERVICE LIGHT RES	(00-..)	

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS


Goldhofer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





















Gontrailer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS

IrisBus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 CityClass	ENGINE MANAGEME	Cursor	BOSCH EDC MS 6.2
 Domino	ENGINE MANAGEME	380	BOSCH EDC M7
 EuroClass HD	BRAKE SYS. MANAGE		Wabco EBS EURO
 EuroClass HD	ENGINE MANAGEME	Cursor	Bosch EDC MS 6.2
 EuroClass ND	BRAKE SYS. MANAGE		Wabco EBS EURO
 Euroclass	ENGINE MANAGEME	380	BOSCH EDC M7
 Mini & Midi (Daily)	ABS + TRACT. CONT	8140 MiniBUS	Bosch ABS/ABD/EBD 5.3
 Mini & Midi (Daily)	ABS + TRACT. CONT	8140 ScuolaBUS	Bosch ABS/ABD/EBD 5.3
 Mini & Midi (Daily)	CLIMA	MiniBUS	Marelli A/C Clima
 Mini & Midi (Daily)	CLIMA	ScuolaBUS	Marelli A/C Clima
 Mini & Midi (Daily)	ENGINE MANAGEME	8140 MiniBUS	Bosch EDC MS6.3
 Mini & Midi (Daily)	ENGINE MANAGEME	8140 ScuolaBUS	Bosch EDC MS6.3
 Mini & Midi (Daily)	IMMOBILIZER		BOSCH
 My way	ENGINE MANAGEME	393	BOSCH EDC M7
 My way	ENGINE MANAGEME	393 E	BOSCH EDC M7
 My way	ENGINE MANAGEME	Cursor	BOSCH EDC MS 6.2
 Touring by ORLANDI (Daily)	ABS + TRACT. CONT	8140 MiniBUS	Bosch ABS/ABD/EBD 5.3
 Touring by ORLANDI (Daily)	CLIMA	MiniBUS	Marelli A/C Clima
 Touring by ORLANDI (Daily)	ENGINE MANAGEME	8140 MiniBUS	Bosch EDC MS6.3
 Touring by ORLANDI (Daily)	IMMOBILIZER		BOSCH

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
Daily & TurboDaily	ABS + TRACT. CONT	29 L 10 FIAE0481A	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	29 L 11 8140	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	29 L 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	29 L 9 8140	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	35 C 10 FIAE0481A	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	35 C 11 8140	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	35 C 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	35 C 13 8140	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	35 C 9 8140	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	35 L 9 8140	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	35 S 11 8140	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	35 S 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	35 S 13 8140	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	40 C 10 FIAE0481A	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	40 C 11 8140	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	40 C 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	40 C 9 8140	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	40 C 9 8140	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	ABS + TRACT. CONT	65 C 15 8140	BOSCH ABS/ABD/EBD 5.3
Daily & TurboDaily	AIRBAG		ALLIED AirBag MY 97 (2F-2P)
Daily & TurboDaily	CLIMA		Marelli A/C Clima
Daily & TurboDaily	ENGINE MANAGEME	2.3 16v F1AE0481A	BOSCH EDC 16 Common Rail
Daily & TurboDaily	ENGINE MANAGEME	29 L 10 FIAE0481A	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	29 L 11 8140	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	29 L 12 FIAE0481B	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	29 L 9 8140	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	35 C 10 FIAE0481A	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	35 C 11 8140	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	35 C 12 FIAE0481B	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	35 C 13 8140	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	35 C 9 8140	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	35 L 9 8140	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	35 S 10 FIAE0481A	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	35 S 11 8140	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	35 S 12 FIAE0481B	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	35 S 13 8140	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	40 C 10 FIAE0481A	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	40 C 11 8140	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	40 C 12 FIAE0481B	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	40 C 13 8140	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	40 C 9 8140	BOSCH EDC MS6.3
Daily & TurboDaily	ENGINE MANAGEME	65 C 15 8140	BOSCH EDC MS6.3
Daily & TurboDaily	IMMOBILIZER		BOSCH
Daily & TurboDaily	KEY ENCODE		BOSCH CODE
EuroCargo	ABS + TRACT. CONT		BOSCH ABS/ASR/SL P4 Full Air
EuroCargo	ABS + TRACT. CONT		WABCO ABS/ASR/EBS C3
EuroCargo	EMERGENCY START	Tector	
EuroCargo	SUSPENSION CONTR	Tector	WABCO ECAS F. P. + CAN
EuroFire	ABS + TRACT. CONT		BOSCH ABS/ASR/SL P4 Full Air
EuroFire	ABS + TRACT. CONT		WABCO ABS/ASR/EBS C3
EuroFire	SUSPENSION CONTR		WABCO ECAS Full Pneumatic
EuroFire	SUSPENSION CONTR		WABCO ECAS Pneumatic
EuroStar	ABS + TRACT. CONT		BOSCH ABS/ASR/SL P4 Full Air
EuroStar	ABS + TRACT. CONT		WABCO ABS/ASR/EBS C3
EuroStar	BRAKE POWER SUPP		ZF Intarder no CAN
EuroStar	BRAKE SYS. MANAGE		WABCO EBS EURO
EuroStar	EMERGENCY START	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
EuroStar	EMERGENCY START	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroStar	EMERGENCY START	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 EuroStar	EMERGENCY START	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 EuroStar	EMERGENCY START	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	180 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	190 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	240 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	260 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	360 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	400 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	470 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 EuroStar	SUSPENSION CONTR		WABCO ECAS Pneumatic
 EuroTech	ABS + TRACT. CONT		Bosch ABS/ASR/SL P4 Full Air
 EuroTech	ABS + TRACT. CONT		WABCO ABS/ASR/EBS C3
 EuroTech	ABS + TRACT. CONT		WABCO EBS EURO
 EuroTech	BRAKE POWER SUPP		ZF Intarder no CAN
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681C	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681D	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681E	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681C	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681D	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681G	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	180 E 38	BOSCH EDC M7
 EuroTech	ENGINE MANAGEME	190 E 38	BOSCH EDC M7
 EuroTech	ENGINE MANAGEME	240 E 38	BOSCH EDC M7
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681C	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681D	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681E	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681C	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681D	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681G	BOSCH EDC MS 6.2
 EuroTech	SUSPENSION CONTR		WABCO ECAS Full Pneumatic

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroTech	SUSPENSION CONTR		WABCO ECAS Pneumatic
 EuroTrakker	ABS + TRACT. CONT		Bosch ABS/ASR/SL P4 Full Air
 EuroTrakker	ABS + TRACT. CONT		WABCO ABS/ASR/EBS C3
 EuroTrakker	BRAKE POWER SUPP		ZF Intarder no CAN
 EuroTrakker	BRAKE SYS. MANAGE	Cursor 13 F3BE0681C	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAGE	Cursor 13 F3BE0681D	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAGE	Cursor 13 F3BE0681E	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAGE	Cursor 13 F3BE0681F	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAGE	Cursor 13 F3BE0681G	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAGE	Cursor 8 F2BE0681A	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAGE	Cursor 8 F2BE0681B	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAGE	Cursor 8 F2BE0681C	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAGE	Cursor 8 F2BE0681D	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAGE	Cursor 8 F2BE0681E	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAGE	Cursor 8 F2BE0681F	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAGE	Cursor 8 F2BE0681G	WABCO EBS EURO
 EuroTrakker	ENGINE MANAGEME	190 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	260 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	340 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	380 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	410 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	440 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	720 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681C	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681D	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681E	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681C	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681D	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681G	BOSCH EDC MS 6.2
 EuroTrakker	SUSPENSION CONTR		WABCO ECAS Full Pneumatic
 EuroTrakker	SUSPENSION CONTR		WABCO ECAS Pneumatic
 New Eurocargo	ABS	100 E 17	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	100 E 18	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	100 E 21	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	60 E 13	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	60 E 15	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	60E13	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	65 E 13	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	65 E 15	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	75 E 13	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	75 E 15	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	75 E 17	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	75 E 18	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	80 E 17	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	80 E 18	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	80 E 21	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	80 EL 15	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	80 EL 17	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	90 E 17	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	90 E 18	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	90 E 21	BOSCH/KNORR ABS 2X
 New Eurocargo	CAN LANES TEST	100 E 17	

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 New Eurocargo	CAN LANES TEST	100 E 18	
 New Eurocargo	CAN LANES TEST	100 E 21	
 New Eurocargo	CAN LANES TEST	60 E 13	
 New Eurocargo	CAN LANES TEST	60 E 15	
 New Eurocargo	CAN LANES TEST	65 E 13	
 New Eurocargo	CAN LANES TEST	65 E 15	
 New Eurocargo	CAN LANES TEST	75 E 13	
 New Eurocargo	CAN LANES TEST	75 E 15	
 New Eurocargo	CAN LANES TEST	75 E 17	
 New Eurocargo	CAN LANES TEST	75 E 18	
 New Eurocargo	CAN LANES TEST	80 E 17	
 New Eurocargo	CAN LANES TEST	80 E 18	
 New Eurocargo	CAN LANES TEST	80 E 21	
 New Eurocargo	CAN LANES TEST	80 EL 15	
 New Eurocargo	CAN LANES TEST	80 EL 17	
 New Eurocargo	CAN LANES TEST	90 E 17	
 New Eurocargo	CAN LANES TEST	90 E 18	
 New Eurocargo	CAN LANES TEST	90 E 21	
 New Eurocargo	CHASSIS NETWORK	100 E 17	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	100 E 18	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	100 E 21	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	60 E 13	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	60 E 15	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	65 E 13	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	65 E 15	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	75 E 13	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	75 E 15	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	75 E 17	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	75 E 18	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	80 E 17	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	80 E 18	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	80 E 21	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	80 EL 15	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	80 EL 17	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	90 E 17	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	90 E 18	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	90 E 21	VDO Body Controller
 New Eurocargo	DASHBOARD	100 E 17	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	100 E 18	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	100 E 21	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	60 E 13	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	60 E 15	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	65 E 13	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	65 E 15	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	75 E 13	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	75 E 15	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	75 E 17	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	75 E 18	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	80 E 17	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	80 E 18	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	80 E 21	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	80 EL 15	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	80 EL 17	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	90 E 17	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	90 E 18	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	90 E 21	VDO Instrument Cluster
 New Eurocargo	EMERGENCY START	100 E 17	
 New Eurocargo	EMERGENCY START	100 E 18	

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS

























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 New Eurocargo	EMERGENCY START	60 E 13	
 New Eurocargo	EMERGENCY START	60 E 15	
 New Eurocargo	EMERGENCY START	65 E 13	
 New Eurocargo	EMERGENCY START	65 E 15	
 New Eurocargo	EMERGENCY START	75 E 13	
 New Eurocargo	EMERGENCY START	75 E 15	
 New Eurocargo	EMERGENCY START	75 E 17	
 New Eurocargo	EMERGENCY START	75 E 18	
 New Eurocargo	EMERGENCY START	80 E 17	
 New Eurocargo	EMERGENCY START	80 E 18	
 New Eurocargo	EMERGENCY START	80 E 21	
 New Eurocargo	EMERGENCY START	80 EL 15	
 New Eurocargo	EMERGENCY START	80 EL 17	
 New Eurocargo	EMERGENCY START	90 E 17	
 New Eurocargo	EMERGENCY START	90 E 18	
 New Eurocargo	ENGINE MANAGEME	Tector 110Kw F4AE481C	BOSCH EDC 7 Tector
 New Eurocargo	SUSPENSION CONTR	100 E 17	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	100 E 18	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	100 E 21	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	60 E 13	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	60 E 15	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	65 E 13	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	65 E 15	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	75 E 13	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	75 E 15	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	75 E 17	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	75 E 18	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	80 E 17	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	80 E 18	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	80 E 21	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	80 EL 15	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	80 EL 17	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	90 E 17	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	90 E 18	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	90 E 21	WABCO ECAS CAN
 Stralis	BRAKE SYS. MANAGE		WABCO EBS EURO
 Stralis	CAN LANES TEST		
 Stralis	CHASSIS NETWORK		Body Computer
 Stralis	CHASSIS NETWORK		Driver Door Module
 Stralis	CHASSIS NETWORK		Front Frame Computer
 Stralis	CHASSIS NETWORK		Passenger Door Module
 Stralis	CHASSIS NETWORK		Rear Frame Computer
 Stralis	DASHBOARD		Instrument Cluster
 Stralis	EMERGENCY START	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS








Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 Stralis	GEARBOX MANAGEM		Eurotronic 2
 Stralis	IMMOBILIZER		
 Stralis	SUSPENSION CONTR		WABCO ECAS + CAN
 Trakker	CAN LANES TEST		
 Trakker	CHASSIS NETWORK		Body Computer
 Trakker	CHASSIS NETWORK		Driver Door Module
 Trakker	CHASSIS NETWORK		Front Frame Computer
 Trakker	CHASSIS NETWORK		Passenger Door Module
 Trakker	CHASSIS NETWORK		Rear Frame Computer
 Trakker	DASHBOARD		Instrument Cluster
 Trakker	EMERGENCY START	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 Trakker	GEARBOX MANAGEM		Eurotronic 2

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Iveco Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series	ENGINE MANAGEME	315	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	316	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	370	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	380	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	391	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	393	BOSCH EDC M7
 Euroreader	ENGINE MANAGEME	391	BOSCH EDC M7

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




Kassbohrer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS + TRACT. CONT	Trailers	Wabco Trailer VCS
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




Kogel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Kraker

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




Krone

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Lecinena

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































MAN

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 F90	ABS	19.322 F-sm	BOSCH ABS/ASR 2E
 F90	ABS	19.322 F-sm	BOSCH ABS/ASR 2M Stufe 1
 F90	ABS	19.322 F-sm	BOSCH ABS/ASR 3E
 F90	ABS	19.322 F-sm	BOSCH ABS/ASR 3M
 F90	ABS	19.322 F-sm	KNORR ABS
 F90	ABS	19.372 F-cl	BOSCH ABS/ASR 2E
 F90	ABS	19.372 F-cl	BOSCH ABS/ASR 2M Stufe 1
 F90	ABS	19.372 F-cl	BOSCH ABS/ASR 3E
 F90	ABS	19.372 F-cl	BOSCH ABS/ASR 3M
 F90	ABS	19.372 F-cl	KNORR ABS
 F90	ABS	19.422 FL-cl	BOSCH ABS/ASR 2E
 F90	ABS	19.422 FL-cl	BOSCH ABS/ASR 2M Stufe 1
 F90	ABS	19.422 FL-cl	BOSCH ABS/ASR 3E
 F90	ABS	19.422 FL-cl	BOSCH ABS/ASR 3M
 F90	ABS	19.422 FL-cl	KNORR ABS
 F90	ABS	19.422 FLT-cl-SPP	BOSCH ABS/ASR 2E
 F90	ABS	19.422 FLT-cl-SPP	BOSCH ABS/ASR 2M Stufe 1
 F90	ABS	19.422 FLT-cl-SPP	BOSCH ABS/ASR 3E
 F90	ABS	19.422 FLT-cl-SPP	BOSCH ABS/ASR 3M
 F90	ABS	19.422 FLT-cl-SPP	KNORR ABS
 F90	DIESEL MANAGEMEN	19.322 F-sm	BOSCH EDC M7
 F90	DIESEL MANAGEMEN	19.372 F-cl	BOSCH EDC M7
 F90	DIESEL MANAGEMEN	19.422 FL-cl	BOSCH EDC M7
 F90	DIESEL MANAGEMEN	19.422 FLT-cl-SPP	BOSCH EDC M7
 F90	SUSPENSION CONTR	19.322 F-sm	ECAS
 F90	SUSPENSION CONTR	19.372 F-cl	ECAS
 F90	SUSPENSION CONTR	19.422 FL-cl	ECAS
 F90	SUSPENSION CONTR	19.422 FLT-cl-SPP	ECAS
 M90	ABS	12.192 F-sm	BOSCH ABS/ASR 2E
 M90	ABS	12.192 F-sm	BOSCH ABS/ASR 2M Stufe 1
 M90	ABS	12.192 F-sm	BOSCH ABS/ASR 3E
 M90	ABS	12.192 F-sm	BOSCH ABS/ASR 3M
 M90	ABS	12.192 F-sm	KNORR ABS
 M90	ABS	12.232 FL-spp	BOSCH ABS/ASR 2E
 M90	ABS	12.232 FL-spp	BOSCH ABS/ASR 2M Stufe 1
 M90	ABS	12.232 FL-spp	BOSCH ABS/ASR 3E
 M90	ABS	12.232 FL-spp	BOSCH ABS/ASR 3M
 M90	ABS	12.232 FL-spp	KNORR ABS
 M90	ABS	12.272 FL-spp	BOSCH ABS/ASR 2E
 M90	ABS	12.272 FL-spp	BOSCH ABS/ASR 2M Stufe 1
 M90	ABS	12.272 FL-spp	BOSCH ABS/ASR 3E
 M90	ABS	12.272 FL-spp	BOSCH ABS/ASR 3M
 M90	ABS	12.272 FL-spp	KNORR ABS
 M90	DIESEL MANAGEMEN	12.192 F-sm	BOSCH EDC M7
 M90	DIESEL MANAGEMEN	12.232 FL-spp	BOSCH EDC M7
 M90	DIESEL MANAGEMEN	12.272 FL-spp	BOSCH EDC M7
 M90	SUSPENSION CONTR	12.192 F-sm	ECAS
 M90	SUSPENSION CONTR	12.232 FL-spp	ECAS
 M90	SUSPENSION CONTR	12.272 FL-spp	ECAS
 TG-A 18.310	AIR BRAKE MANAGE		HALDEX ECAM
 TG-A 18.310	AUTOM. TRANSMISSI		ZF ASTRONIC 2
 TG-A 18.310	BRAKE POWER SUPP		ZF Intarder
 TG-A 18.310	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 2 axle
 TG-A 18.310	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 3 axle
 TG-A 18.310	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 4 axle
 TG-A 18.310	BRAKE SYS. MANAGE		KNORR EBS 2.3 - axle 3 trained
 TG-A 18.310	CHASSIS NETWORK		Berifors Door Module
 TG-A 18.310	CHASSIS NETWORK		WABCO Body Computer ZBR 2

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































MAN

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 18.310	CLIMA		Behr/Gkr
 TG-A 18.310	CRUISE MANAGEMEN		VDO Navigator
 TG-A 18.310	DASHBOARD		VDO/Kienzle
 TG-A 18.310	ENGINE MANAGEME	D2066LF01	BOSCH EDC 7
 TG-A 18.310	ENGINE MANAGEME	D2066LF02	BOSCH EDC 7
 TG-A 18.310	ENGINE MANAGEME	D2066LF03	BOSCH EDC 7
 TG-A 18.310	ENGINE MANAGEME	D2066LF04	BOSCH EDC 7
 TG-A 18.310	ENGINE MANAGEME	D2866LF26	BOSCH EDC MS 6.1
 TG-A 18.310	ENGINE MANAGEME	D2866LF27	BOSCH EDC MS 6.1
 TG-A 18.310	ENGINE MANAGEME	D2866LF28	BOSCH EDC MS 6.1
 TG-A 18.310	ENGINE MANAGEME	D2866LF32	BOSCH EDC MS 6.1
 TG-A 18.310	ENGINE MANAGEME	D2866LF36	BOSCH EDC MS 6.1
 TG-A 18.310	ENGINE MANAGEME	D2866LF37	BOSCH EDC MS 6.1
 TG-A 18.310	ENGINE MANAGEME	D2876LF04	BOSCH EDC MS 6.1
 TG-A 18.310	ENGINE MANAGEME	D2876LF07	BOSCH EDC MS 6.1
 TG-A 18.310	SUSPENSION CONTR		WABCO ECAS
 TG-A 18.360	AIR BRAKE MANAGE		HALDEX ECAM
 TG-A 18.360	AUTOM. TRANSMISSI		ZF ASTRONIC 2
 TG-A 18.360	BRAKE POWER SUPP		ZF Intarder
 TG-A 18.360	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 2 axle
 TG-A 18.360	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 3 axle
 TG-A 18.360	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 4 axle
 TG-A 18.360	BRAKE SYS. MANAGE		KNORR EBS 2.3 - axle 3 trained
 TG-A 18.360	CHASSIS NETWORK		Berifors Door Module
 TG-A 18.360	CHASSIS NETWORK		WABCO Body Computer ZBR 2
 TG-A 18.360	CLIMA		Behr/Gkr
 TG-A 18.360	CRUISE MANAGEMEN		VDO Navigator
 TG-A 18.360	DASHBOARD		VDO/Kienzle
 TG-A 18.360	ENGINE MANAGEME	D2066LF01	BOSCH EDC 7
 TG-A 18.360	ENGINE MANAGEME	D2066LF02	BOSCH EDC 7
 TG-A 18.360	ENGINE MANAGEME	D2066LF03	BOSCH EDC 7
 TG-A 18.360	ENGINE MANAGEME	D2066LF04	BOSCH EDC 7
 TG-A 18.360	ENGINE MANAGEME	D2866LF26	BOSCH EDC MS 6.1
 TG-A 18.360	ENGINE MANAGEME	D2866LF27	BOSCH EDC MS 6.1
 TG-A 18.360	ENGINE MANAGEME	D2866LF28	BOSCH EDC MS 6.1
 TG-A 18.360	ENGINE MANAGEME	D2866LF32	BOSCH EDC MS 6.1
 TG-A 18.360	ENGINE MANAGEME	D2866LF36	BOSCH EDC MS 6.1
 TG-A 18.360	ENGINE MANAGEME	D2866LF37	BOSCH EDC MS 6.1
 TG-A 18.360	ENGINE MANAGEME	D2876LF04	BOSCH EDC MS 6.1
 TG-A 18.360	ENGINE MANAGEME	D2876LF07	BOSCH EDC MS 6.1
 TG-A 18.360	SUSPENSION CONTR		WABCO ECAS
 TG-A 18.410	AIR BRAKE MANAGE		HALDEX ECAM
 TG-A 18.410	AUTOM. TRANSMISSI		ZF ASTRONIC 2
 TG-A 18.410	BRAKE POWER SUPP		ZF Intarder
 TG-A 18.410	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 2 axle
 TG-A 18.410	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 3 axle
 TG-A 18.410	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 4 axle
 TG-A 18.410	BRAKE SYS. MANAGE		KNORR EBS 2.3 - axle 3 trained
 TG-A 18.410	CHASSIS NETWORK		Berifors Door Module
 TG-A 18.410	CHASSIS NETWORK		WABCO Body Computer ZBR 2
 TG-A 18.410	CLIMA		Behr/Gkr
 TG-A 18.410	CRUISE MANAGEMEN		VDO Navigator
 TG-A 18.410	DASHBOARD		VDO/Kienzle
 TG-A 18.410	ENGINE MANAGEME	D2066LF01	BOSCH EDC 7
 TG-A 18.410	ENGINE MANAGEME	D2066LF02	BOSCH EDC 7
 TG-A 18.410	ENGINE MANAGEME	D2066LF03	BOSCH EDC 7
 TG-A 18.410	ENGINE MANAGEME	D2066LF04	BOSCH EDC 7
 TG-A 18.410	ENGINE MANAGEME	D2866LF26	BOSCH EDC MS 6.1

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































MAN

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 18.410	ENGINE MANAGEME	D2866LF27	BOSCH EDC MS 6.1
 TG-A 18.410	ENGINE MANAGEME	D2866LF28	BOSCH EDC MS 6.1
 TG-A 18.410	ENGINE MANAGEME	D2866LF32	BOSCH EDC MS 6.1
 TG-A 18.410	ENGINE MANAGEME	D2866LF36	BOSCH EDC MS 6.1
 TG-A 18.410	ENGINE MANAGEME	D2866LF37	BOSCH EDC MS 6.1
 TG-A 18.410	ENGINE MANAGEME	D2876LF04	BOSCH EDC MS 6.1
 TG-A 18.410	ENGINE MANAGEME	D2876LF07	BOSCH EDC MS 6.1
 TG-A 18.410	SUSPENSION CONTR		WABCO ECAS
 TG-A 18.460	AIR BRAKE MANAGE		HALDEX ECAM
 TG-A 18.460	AUTOM. TRANSMISSI		ZF ASTRONIC 2
 TG-A 18.460	BRAKE POWER SUPP		ZF Intarder
 TG-A 18.460	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 2 axle
 TG-A 18.460	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 3 axle
 TG-A 18.460	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 4 axle
 TG-A 18.460	BRAKE SYS. MANAGE		KNORR EBS 2.3 - axle 3 trained
 TG-A 18.460	CHASSIS NETWORK		Berifors Door Module
 TG-A 18.460	CHASSIS NETWORK		WABCO Body Computer ZBR 2
 TG-A 18.460	CLIMA		Behr/Gkr
 TG-A 18.460	CRUISE MANAGEMEN		VDO Navigator
 TG-A 18.460	DASHBOARD		VDO/Kienzle
 TG-A 18.460	ENGINE MANAGEME	D2066LF01	BOSCH EDC 7
 TG-A 18.460	ENGINE MANAGEME	D2066LF02	BOSCH EDC 7
 TG-A 18.460	ENGINE MANAGEME	D2066LF03	BOSCH EDC 7
 TG-A 18.460	ENGINE MANAGEME	D2066LF04	BOSCH EDC 7
 TG-A 18.460	ENGINE MANAGEME	D2866LF26	BOSCH EDC MS 6.1
 TG-A 18.460	ENGINE MANAGEME	D2866LF27	BOSCH EDC MS 6.1
 TG-A 18.460	ENGINE MANAGEME	D2866LF28	BOSCH EDC MS 6.1
 TG-A 18.460	ENGINE MANAGEME	D2866LF32	BOSCH EDC MS 6.1
 TG-A 18.460	ENGINE MANAGEME	D2866LF36	BOSCH EDC MS 6.1
 TG-A 18.460	ENGINE MANAGEME	D2866LF37	BOSCH EDC MS 6.1
 TG-A 18.460	ENGINE MANAGEME	D2876LF04	BOSCH EDC MS 6.1
 TG-A 18.460	ENGINE MANAGEME	D2876LF07	BOSCH EDC MS 6.1
 TG-A 18.460	SUSPENSION CONTR		WABCO ECAS
 TG-A 18.480	AIR BRAKE MANAGE		HALDEX ECAM
 TG-A 18.480	AUTOM. TRANSMISSI		ZF ASTRONIC 2
 TG-A 18.480	BRAKE POWER SUPP		ZF Intarder
 TG-A 18.480	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 2 axle
 TG-A 18.480	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 3 axle
 TG-A 18.480	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 4 axle
 TG-A 18.480	BRAKE SYS. MANAGE		KNORR EBS 2.3 - axle 3 trained
 TG-A 18.480	CHASSIS NETWORK		Berifors Door Module
 TG-A 18.480	CHASSIS NETWORK		WABCO Body Computer ZBR 2
 TG-A 18.480	CLIMA		Behr/Gkr
 TG-A 18.480	CRUISE MANAGEMEN		VDO Navigator
 TG-A 18.480	DASHBOARD		VDO/Kienzle
 TG-A 18.480	ENGINE MANAGEME	D2066LF01	BOSCH EDC 7
 TG-A 18.480	ENGINE MANAGEME	D2066LF02	BOSCH EDC 7
 TG-A 18.480	ENGINE MANAGEME	D2066LF03	BOSCH EDC 7
 TG-A 18.480	ENGINE MANAGEME	D2066LF04	BOSCH EDC 7
 TG-A 18.480	ENGINE MANAGEME	D2866LF26	BOSCH EDC MS 6.1
 TG-A 18.480	ENGINE MANAGEME	D2866LF27	BOSCH EDC MS 6.1
 TG-A 18.480	ENGINE MANAGEME	D2866LF28	BOSCH EDC MS 6.1
 TG-A 18.480	ENGINE MANAGEME	D2866LF32	BOSCH EDC MS 6.1
 TG-A 18.480	ENGINE MANAGEME	D2866LF36	BOSCH EDC MS 6.1
 TG-A 18.480	ENGINE MANAGEME	D2866LF37	BOSCH EDC MS 6.1
 TG-A 18.480	ENGINE MANAGEME	D2876LF04	BOSCH EDC MS 6.1
 TG-A 18.480	ENGINE MANAGEME	D2876LF07	BOSCH EDC MS 6.1
 TG-A 18.480	SUSPENSION CONTR		WABCO ECAS

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































MAN

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 18.510	BRAKE POWER SUPP		ZF Intarder
 TG-A 18.510	CRUISE MANAGEMEN		VDO Navigator
 TG-A 18.530	AIR BRAKE MANAGE		HALDEX ECAM
 TG-A 18.530	AUTOM. TRANSMISSI		ZF ASTRONIC 2
 TG-A 18.530	BRAKE POWER SUPP		ZF Intarder
 TG-A 18.530	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 2 axle
 TG-A 18.530	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 3 axle
 TG-A 18.530	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 4 axle
 TG-A 18.530	BRAKE SYS. MANAGE		KNORR EBS 2.3 - axle 3 trained
 TG-A 18.530	CHASSIS NETWORK		Berifors Door Module
 TG-A 18.530	CHASSIS NETWORK		WABCO Body Computer ZBR 2
 TG-A 18.530	CLIMA		Behr/Gkr
 TG-A 18.530	CRUISE MANAGEMEN		VDO Navigator
 TG-A 18.530	DASHBOARD		VDO/Kienzle
 TG-A 18.530	ENGINE MANAGEME	D2066LF01	BOSCH EDC 7
 TG-A 18.530	ENGINE MANAGEME	D2066LF02	BOSCH EDC 7
 TG-A 18.530	ENGINE MANAGEME	D2066LF03	BOSCH EDC 7
 TG-A 18.530	ENGINE MANAGEME	D2066LF04	BOSCH EDC 7
 TG-A 18.530	ENGINE MANAGEME	D2866LF26	BOSCH EDC MS 6.1
 TG-A 18.530	ENGINE MANAGEME	D2866LF27	BOSCH EDC MS 6.1
 TG-A 18.530	ENGINE MANAGEME	D2866LF28	BOSCH EDC MS 6.1
 TG-A 18.530	ENGINE MANAGEME	D2866LF32	BOSCH EDC MS 6.1
 TG-A 18.530	ENGINE MANAGEME	D2866LF36	BOSCH EDC MS 6.1
 TG-A 18.530	ENGINE MANAGEME	D2866LF37	BOSCH EDC MS 6.1
 TG-A 18.530	ENGINE MANAGEME	D2876LF04	BOSCH EDC MS 6.1
 TG-A 18.530	ENGINE MANAGEME	D2876LF07	BOSCH EDC MS 6.1
 TG-A 18.530	SUSPENSION CONTR		WABCO ECAS
 TG-A 26.310	AIR BRAKE MANAGE		HALDEX ECAM
 TG-A 26.310	AUTOM. TRANSMISSI		ZF ASTRONIC 2
 TG-A 26.310	BRAKE POWER SUPP		ZF Intarder
 TG-A 26.310	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 2 axle
 TG-A 26.310	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 3 axle
 TG-A 26.310	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 4 axle
 TG-A 26.310	BRAKE SYS. MANAGE		KNORR EBS 2.3 - axle 3 trained
 TG-A 26.310	CHASSIS NETWORK		Berifors Door Module
 TG-A 26.310	CHASSIS NETWORK		WABCO Body Computer ZBR 2
 TG-A 26.310	CLIMA		Behr/Gkr
 TG-A 26.310	CRUISE MANAGEMEN		VDO Navigator
 TG-A 26.310	DASHBOARD		VDO/Kienzle
 TG-A 26.310	ENGINE MANAGEME	D2066LF01	BOSCH EDC 7
 TG-A 26.310	ENGINE MANAGEME	D2066LF02	BOSCH EDC 7
 TG-A 26.310	ENGINE MANAGEME	D2066LF03	BOSCH EDC 7
 TG-A 26.310	ENGINE MANAGEME	D2066LF04	BOSCH EDC 7
 TG-A 26.310	ENGINE MANAGEME	D2866LF26	BOSCH EDC MS 6.1
 TG-A 26.310	ENGINE MANAGEME	D2866LF27	BOSCH EDC MS 6.1
 TG-A 26.310	ENGINE MANAGEME	D2866LF28	BOSCH EDC MS 6.1
 TG-A 26.310	ENGINE MANAGEME	D2866LF32	BOSCH EDC MS 6.1
 TG-A 26.310	ENGINE MANAGEME	D2866LF36	BOSCH EDC MS 6.1
 TG-A 26.310	ENGINE MANAGEME	D2866LF37	BOSCH EDC MS 6.1
 TG-A 26.310	ENGINE MANAGEME	D2876LF04	BOSCH EDC MS 6.1
 TG-A 26.310	ENGINE MANAGEME	D2876LF07	BOSCH EDC MS 6.1
 TG-A 26.310	SUSPENSION CONTR		WABCO ECAS
 TG-A 26.360	AIR BRAKE MANAGE		HALDEX ECAM
 TG-A 26.360	AUTOM. TRANSMISSI		ZF ASTRONIC 2
 TG-A 26.360	BRAKE POWER SUPP		ZF Intarder
 TG-A 26.360	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 2 axle
 TG-A 26.360	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 3 axle
 TG-A 26.360	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 4 axle

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































MAN

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 26.360	BRAKE SYS. MANAGE		KNORR EBS 2.3 - axle 3 trained
 TG-A 26.360	CHASSIS NETWORK		Berifors Door Module
 TG-A 26.360	CHASSIS NETWORK		WABCO Body Computer ZBR 2
 TG-A 26.360	CLIMA		Behr/Gkr
 TG-A 26.360	CRUISE MANAGEMEN		VDO Navigator
 TG-A 26.360	DASHBOARD		VDO/Kienzle
 TG-A 26.360	ENGINE MANAGEME	D2066LF01	BOSCH EDC 7
 TG-A 26.360	ENGINE MANAGEME	D2066LF02	BOSCH EDC 7
 TG-A 26.360	ENGINE MANAGEME	D2066LF03	BOSCH EDC 7
 TG-A 26.360	ENGINE MANAGEME	D2066LF04	BOSCH EDC 7
 TG-A 26.360	ENGINE MANAGEME	D2866LF26	BOSCH EDC MS 6.1
 TG-A 26.360	ENGINE MANAGEME	D2866LF27	BOSCH EDC MS 6.1
 TG-A 26.360	ENGINE MANAGEME	D2866LF28	BOSCH EDC MS 6.1
 TG-A 26.360	ENGINE MANAGEME	D2866LF32	BOSCH EDC MS 6.1
 TG-A 26.360	ENGINE MANAGEME	D2866LF36	BOSCH EDC MS 6.1
 TG-A 26.360	ENGINE MANAGEME	D2866LF37	BOSCH EDC MS 6.1
 TG-A 26.360	ENGINE MANAGEME	D2876LF04	BOSCH EDC MS 6.1
 TG-A 26.360	ENGINE MANAGEME	D2876LF07	BOSCH EDC MS 6.1
 TG-A 26.360	SUSPENSION CONTR		WABCO ECAS
 TG-A 26.410	AIR BRAKE MANAGE		HALDEX ECAM
 TG-A 26.410	AUTOM. TRANSMISSI		ZF ASTRONIC 2
 TG-A 26.410	BRAKE POWER SUPP		ZF Intarder
 TG-A 26.410	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 2 axle
 TG-A 26.410	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 3 axle
 TG-A 26.410	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 4 axle
 TG-A 26.410	BRAKE SYS. MANAGE		KNORR EBS 2.3 - axle 3 trained
 TG-A 26.410	CHASSIS NETWORK		Berifors Door Module
 TG-A 26.410	CHASSIS NETWORK		WABCO Body Computer ZBR 2
 TG-A 26.410	CLIMA		Behr/Gkr
 TG-A 26.410	CRUISE MANAGEMEN		VDO Navigator
 TG-A 26.410	DASHBOARD		VDO/Kienzle
 TG-A 26.410	ENGINE MANAGEME	D2066LF01	BOSCH EDC 7
 TG-A 26.410	ENGINE MANAGEME	D2066LF02	BOSCH EDC 7
 TG-A 26.410	ENGINE MANAGEME	D2066LF03	BOSCH EDC 7
 TG-A 26.410	ENGINE MANAGEME	D2066LF04	BOSCH EDC 7
 TG-A 26.410	ENGINE MANAGEME	D2866LF26	BOSCH EDC MS 6.1
 TG-A 26.410	ENGINE MANAGEME	D2866LF27	BOSCH EDC MS 6.1
 TG-A 26.410	ENGINE MANAGEME	D2866LF28	BOSCH EDC MS 6.1
 TG-A 26.410	ENGINE MANAGEME	D2866LF32	BOSCH EDC MS 6.1
 TG-A 26.410	ENGINE MANAGEME	D2866LF36	BOSCH EDC MS 6.1
 TG-A 26.410	ENGINE MANAGEME	D2866LF37	BOSCH EDC MS 6.1
 TG-A 26.410	ENGINE MANAGEME	D2876LF04	BOSCH EDC MS 6.1
 TG-A 26.410	ENGINE MANAGEME	D2876LF07	BOSCH EDC MS 6.1
 TG-A 26.410	SUSPENSION CONTR		WABCO ECAS
 TG-A 26.460	AIR BRAKE MANAGE		HALDEX ECAM
 TG-A 26.460	AUTOM. TRANSMISSI		ZF ASTRONIC 2
 TG-A 26.460	BRAKE POWER SUPP		ZF Intarder
 TG-A 26.460	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 2 axle
 TG-A 26.460	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 3 axle
 TG-A 26.460	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 4 axle
 TG-A 26.460	BRAKE SYS. MANAGE		KNORR EBS 2.3 - axle 3 trained
 TG-A 26.460	CHASSIS NETWORK		Berifors Door Module
 TG-A 26.460	CHASSIS NETWORK		WABCO Body Computer ZBR 2
 TG-A 26.460	CLIMA		Behr/Gkr
 TG-A 26.460	CRUISE MANAGEMEN		VDO Navigator
 TG-A 26.460	DASHBOARD		VDO/Kienzle
 TG-A 26.460	ENGINE MANAGEME	D2066LF01	BOSCH EDC 7
 TG-A 26.460	ENGINE MANAGEME	D2066LF02	BOSCH EDC 7

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




MAN

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 26.460	ENGINE MANAGEME	D2066LF03	BOSCH EDC 7
 TG-A 26.460	ENGINE MANAGEME	D2066LF04	BOSCH EDC 7
 TG-A 26.460	ENGINE MANAGEME	D2866LF26	BOSCH EDC MS 6.1
 TG-A 26.460	ENGINE MANAGEME	D2866LF27	BOSCH EDC MS 6.1
 TG-A 26.460	ENGINE MANAGEME	D2866LF28	BOSCH EDC MS 6.1
 TG-A 26.460	ENGINE MANAGEME	D2866LF32	BOSCH EDC MS 6.1
 TG-A 26.460	ENGINE MANAGEME	D2866LF36	BOSCH EDC MS 6.1
 TG-A 26.460	ENGINE MANAGEME	D2866LF37	BOSCH EDC MS 6.1
 TG-A 26.460	ENGINE MANAGEME	D2876LF04	BOSCH EDC MS 6.1
 TG-A 26.460	ENGINE MANAGEME	D2876LF07	BOSCH EDC MS 6.1
 TG-A 26.460	SUSPENSION CONTR		WABCO ECAS
 TG-A 26.480	AIR BRAKE MANAGE		HALDEX ECAM
 TG-A 26.480	AUTOM. TRANSMISSI		ZF ASTRONIC 2
 TG-A 26.480	BRAKE POWER SUPP		ZF Intarder
 TG-A 26.480	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 2 axle
 TG-A 26.480	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 3 axle
 TG-A 26.480	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 4 axle
 TG-A 26.480	BRAKE SYS. MANAGE		KNORR EBS 2.3 - axle 3 trained
 TG-A 26.480	CHASSIS NETWORK		Berifors Door Module
 TG-A 26.480	CHASSIS NETWORK		WABCO Body Computer ZBR 2
 TG-A 26.480	CLIMA		Behr/Gkr
 TG-A 26.480	CRUISE MANAGEMEN		VDO Navigator
 TG-A 26.480	DASHBOARD		VDO/Kienzle
 TG-A 26.480	ENGINE MANAGEME	D2066LF01	BOSCH EDC 7
 TG-A 26.480	ENGINE MANAGEME	D2066LF02	BOSCH EDC 7
 TG-A 26.480	ENGINE MANAGEME	D2066LF03	BOSCH EDC 7
 TG-A 26.480	ENGINE MANAGEME	D2066LF04	BOSCH EDC 7
 TG-A 26.480	ENGINE MANAGEME	D2866LF26	BOSCH EDC MS 6.1
 TG-A 26.480	ENGINE MANAGEME	D2866LF27	BOSCH EDC MS 6.1
 TG-A 26.480	ENGINE MANAGEME	D2866LF28	BOSCH EDC MS 6.1
 TG-A 26.480	ENGINE MANAGEME	D2866LF32	BOSCH EDC MS 6.1
 TG-A 26.480	ENGINE MANAGEME	D2866LF36	BOSCH EDC MS 6.1
 TG-A 26.480	ENGINE MANAGEME	D2866LF37	BOSCH EDC MS 6.1
 TG-A 26.480	ENGINE MANAGEME	D2876LF04	BOSCH EDC MS 6.1
 TG-A 26.480	ENGINE MANAGEME	D2876LF07	BOSCH EDC MS 6.1
 TG-A 26.480	SUSPENSION CONTR		WABCO ECAS
 TG-A 26.530	AIR BRAKE MANAGE		HALDEX ECAM
 TG-A 26.530	AUTOM. TRANSMISSI		ZF ASTRONIC 2
 TG-A 26.530	BRAKE POWER SUPP		ZF Intarder
 TG-A 26.530	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 2 axle
 TG-A 26.530	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 3 axle
 TG-A 26.530	BRAKE SYS. MANAGE		KNORR EBS 2.3 - 4 axle
 TG-A 26.530	BRAKE SYS. MANAGE		KNORR EBS 2.3 - axle 3 trained
 TG-A 26.530	CHASSIS NETWORK		Berifors Door Module
 TG-A 26.530	CHASSIS NETWORK		WABCO Body Computer ZBR 2
 TG-A 26.530	CLIMA		Behr/Gkr
 TG-A 26.530	CRUISE MANAGEMEN		VDO Navigator
 TG-A 26.530	DASHBOARD		VDO/Kienzle
 TG-A 26.530	ENGINE MANAGEME	D2066LF01	BOSCH EDC 7
 TG-A 26.530	ENGINE MANAGEME	D2066LF02	BOSCH EDC 7
 TG-A 26.530	ENGINE MANAGEME	D2066LF03	BOSCH EDC 7
 TG-A 26.530	ENGINE MANAGEME	D2066LF04	BOSCH EDC 7
 TG-A 26.530	ENGINE MANAGEME	D2866LF26	BOSCH EDC MS 6.1
 TG-A 26.530	ENGINE MANAGEME	D2866LF27	BOSCH EDC MS 6.1
 TG-A 26.530	ENGINE MANAGEME	D2866LF28	BOSCH EDC MS 6.1
 TG-A 26.530	ENGINE MANAGEME	D2866LF32	BOSCH EDC MS 6.1
 TG-A 26.530	ENGINE MANAGEME	D2866LF36	BOSCH EDC MS 6.1
 TG-A 26.530	ENGINE MANAGEME	D2866LF37	BOSCH EDC MS 6.1

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




MAN

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 26.530	ENGINE MANAGEME	D2876LF04	BOSCH EDC MS 6.1
 TG-A 26.530	ENGINE MANAGEME	D2876LF07	BOSCH EDC MS 6.1
 TG-A 26.530	SUSPENSION CONTR		WABCO ECAS

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Meiller-Kipper

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Menci

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS + TRACT. CONT	Trailers	Wabco Trailer VCS
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS























Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	DIESEL MANAGEMEN	312 D (2.9 D) 602980 (96-..)	BOSCH EVE
 Sprinter	ENGINE MANAGEME	208 CDI	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	211 CDI	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	213 CDI	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	216 CDI	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	308 CDI	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	311 CDI	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	313 CDI	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	316 CDI	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	408 CDI	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	411 CDI	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	413 CDI	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	416 CDI	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	616 CDI	BOSCH EDC Common Rail
 Sprinter	SERVICE LIGHT RES	(99-03)	VDO/MARELLI
 V-Class & VITO	ABS + TRACT. CONT	V 200 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 200 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	V 220 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 220 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	V 230	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 230 (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	V 280	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 280 (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 108 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 108 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 108 D	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 108 D (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 110 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 110 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 110 TD	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 110 TD (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 112 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 112 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 113 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 113 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 114 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 114 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 108 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 108 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 108 D	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 108 D (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 110 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 110 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 110 TD	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 110 TD (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 112 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 112 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 113 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 113 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 114 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 114 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	AUTOM. TRANSMISSI	V 200 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	V 220 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	V 230 (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	V 280 (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 108 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 108 D (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 110 CDI (...99)	BOSCH ETC 6

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 110 TD (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 112 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 113 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 114 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 108 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 108 D (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 110 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 110 TD (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 112 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 113 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 114 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	ENGINE MANAGEME	V 114 111 (...99)	BOSCH Motronic ME 2.0
 V-Class & VITO	ENGINE MANAGEME	V 200 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 200 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 220 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 220 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 230 111 (...99)	BOSCH Motronic ME 2.0
 V-Class & VITO	ENGINE MANAGEME	Vito F 108 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 V-Class & VITO	ENGINE MANAGEME	Vito F 108 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	ENGINE MANAGEME	Vito L 108 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 V-Class & VITO	ENGINE MANAGEME	Vito L 108 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	SERVICE LIGHT RES	(99-03)	VDO/MARELLI

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	ABS	1831 (...00)	MB ABS
 Actros (...00)	ABS	1831 K (...00)	MB ABS
 Actros (...00)	ABS	1831 L (...00)	MB ABS
 Actros (...00)	ABS	1831 L nR (...00)	MB ABS
 Actros (...00)	ABS	1835 L (...00)	MB ABS
 Actros (...00)	ABS	1835 L nR (...00)	MB ABS
 Actros (...00)	ABS	1840 (...00)	MB ABS
 Actros (...00)	ABS	1840 K (...00)	MB ABS
 Actros (...00)	ABS	1840 L (...00)	MB ABS
 Actros (...00)	ABS	1840 L nR (...00)	MB ABS
 Actros (...00)	ABS	1843 (...00)	MB ABS
 Actros (...00)	ABS	1843 K (...00)	MB ABS
 Actros (...00)	ABS	1843 L (...00)	MB ABS
 Actros (...00)	ABS	1843 L nR (...00)	MB ABS
 Actros (...00)	ABS	1846 (...00)	MB ABS
 Actros (...00)	ABS	1846 L (...00)	MB ABS
 Actros (...00)	ABS	1848 (...00)	MB ABS
 Actros (...00)	ABS	1848 L (...00)	MB ABS
 Actros (...00)	ABS	1853 L (...00)	MB ABS
 Actros (...00)	ABS	1857 L (...00)	MB ABS
 Actros (...00)	ABS	2031 AK (...00)	MB ABS
 Actros (...00)	ABS	2531 L (...00)	MB ABS
 Actros (...00)	ABS	2535 L (...00)	MB ABS
 Actros (...00)	ABS	2540 L (...00)	MB ABS
 Actros (...00)	ABS	2543 L (...00)	MB ABS
 Actros (...00)	ABS	2546 L (...00)	MB ABS
 Actros (...00)	ABS	2548 L (...00)	MB ABS
 Actros (...00)	ABS	2553 L (...00)	MB ABS
 Actros (...00)	ABS	2557 L (...00)	MB ABS
 Actros (...00)	ABS	3243 (...00)	MB ABS
 Actros (...00)	ABS	3335 B (...00)	MB ABS
 Actros (...00)	ABS	3335 K (...00)	MB ABS
 Actros (...00)	ABS	3340 AK (...00)	MB ABS
 Actros (...00)	ABS	3340 B (...00)	MB ABS
 Actros (...00)	ABS	3340 K (...00)	MB ABS
 Actros (...00)	ABS	3343 K (...00)	MB ABS
 Actros (...00)	ABS	3346 K (...00)	MB ABS
 Actros (...00)	ABS	3348 K (...00)	MB ABS
 Actros (...00)	ABS	4140 B (...00)	MB ABS
 Actros (...00)	ABS	4140 K (...00)	MB ABS
 Actros (...00)	ABS	4143 K (...00)	MB ABS
 Actros (...00)	ABS	4146 K (...00)	MB ABS
 Actros (...00)	ABS	4148 K (...00)	MB ABS
 Actros (...00)	BRAKE POWER SUPP	1831 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1831 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1831 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1831 L nR (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1835 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1835 L nR (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1840 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1840 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1840 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1840 L nR (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1843 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1843 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1843 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1843 L nR (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1846 (...00)	MB RS Retarder

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	BRAKE POWER SUPP	1846 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1848 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1848 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1853 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	1857 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	2031 AK (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	2531 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	2535 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	2540 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	2543 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	2546 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	2548 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	2553 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	2557 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	3243 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	3335 B (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	3335 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	3340 AK (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	3340 B (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	3340 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	3343 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	3346 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	3348 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	4140 B (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	4140 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	4143 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	4146 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUPP	4148 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE SYS. MANAGE	1831 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1831 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1831 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1831 L nR (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1835 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1835 L nR (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1840 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1840 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1840 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1840 L nR (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1843 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1843 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1843 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1843 L nR (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1846 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1846 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1848 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1848 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1853 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	1857 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	2031 AK (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	2531 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	2535 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	2540 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	2543 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	2546 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	2548 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	2553 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	2557 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	3243 (...00)	MB BS EPB

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS

Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	BRAKE SYS. MANAGE	3335 B (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	3335 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	3340 AK (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	3340 B (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	3340 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	3343 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	3346 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	3348 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	4140 B (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	4140 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	4143 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	4146 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAGE	4148 K (...00)	MB BS EPB
 Actros (...00)	CLIMA	1831 (...00)	MB HZR
 Actros (...00)	CLIMA	1831 K (...00)	MB HZR
 Actros (...00)	CLIMA	1831 L (...00)	MB HZR
 Actros (...00)	CLIMA	1831 L nR (...00)	MB HZR
 Actros (...00)	CLIMA	1835 L (...00)	MB HZR
 Actros (...00)	CLIMA	1835 L nR (...00)	MB HZR
 Actros (...00)	CLIMA	1840 (...00)	MB HZR
 Actros (...00)	CLIMA	1840 K (...00)	MB HZR
 Actros (...00)	CLIMA	1840 L (...00)	MB HZR
 Actros (...00)	CLIMA	1840 L nR (...00)	MB HZR
 Actros (...00)	CLIMA	1843 (...00)	MB HZR
 Actros (...00)	CLIMA	1843 K (...00)	MB HZR
 Actros (...00)	CLIMA	1843 L (...00)	MB HZR
 Actros (...00)	CLIMA	1843 L nR (...00)	MB HZR
 Actros (...00)	CLIMA	1846 (...00)	MB HZR
 Actros (...00)	CLIMA	1846 L (...00)	MB HZR
 Actros (...00)	CLIMA	1848 (...00)	MB HZR
 Actros (...00)	CLIMA	1848 L (...00)	MB HZR
 Actros (...00)	CLIMA	1853 L (...00)	MB HZR
 Actros (...00)	CLIMA	1857 L (...00)	MB HZR
 Actros (...00)	CLIMA	2031 AK (...00)	MB HZR
 Actros (...00)	CLIMA	2531 L (...00)	MB HZR
 Actros (...00)	CLIMA	2535 L (...00)	MB HZR
 Actros (...00)	CLIMA	2540 L (...00)	MB HZR
 Actros (...00)	CLIMA	2543 L (...00)	MB HZR
 Actros (...00)	CLIMA	2546 L (...00)	MB HZR
 Actros (...00)	CLIMA	2548 L (...00)	MB HZR
 Actros (...00)	CLIMA	2553 L (...00)	MB HZR
 Actros (...00)	CLIMA	2557 L (...00)	MB HZR
 Actros (...00)	CLIMA	3243 (...00)	MB HZR
 Actros (...00)	CLIMA	3335 B (...00)	MB HZR
 Actros (...00)	CLIMA	3335 K (...00)	MB HZR
 Actros (...00)	CLIMA	3340 AK (...00)	MB HZR
 Actros (...00)	CLIMA	3340 B (...00)	MB HZR
 Actros (...00)	CLIMA	3340 K (...00)	MB HZR
 Actros (...00)	CLIMA	3343 K (...00)	MB HZR
 Actros (...00)	CLIMA	3346 K (...00)	MB HZR
 Actros (...00)	CLIMA	3348 K (...00)	MB HZR
 Actros (...00)	CLIMA	4140 B (...00)	MB HZR
 Actros (...00)	CLIMA	4140 K (...00)	MB HZR
 Actros (...00)	CLIMA	4143 K (...00)	MB HZR
 Actros (...00)	CLIMA	4146 K (...00)	MB HZR
 Actros (...00)	CLIMA	4148 K (...00)	MB HZR
 Actros (...00)	CLUTCH ELECTRONI	1831 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1831 K (...00)	MB KS MKR

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	CLUTCH ELECTRONI	1831 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1831 L nR (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1835 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1835 L nR (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1840 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1840 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1840 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1840 L nR (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1843 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1843 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1843 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1843 L nR (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1846 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1846 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1848 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1848 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1853 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1857 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2031 AK (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2531 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2535 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2540 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2543 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2546 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2548 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2553 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2557 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3243 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3335 B (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3335 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3340 AK (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3340 B (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3340 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3343 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3346 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3348 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4140 B (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4140 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4143 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4146 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4148 K (...00)	MB KS MKR
 Actros (...00)	CRUISE MANAGEMEN	1831 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1831 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1831 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1831 L nR (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1835 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1835 L nR (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1840 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1840 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1840 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1840 L nR (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1843 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1843 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1843 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1843 L nR (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1846 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1846 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1848 (...00)	FR FMR

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	CRUISE MANAGEMEN	1848 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1853 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	1857 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	2031 AK (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	2531 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	2535 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	2540 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	2543 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	2546 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	2548 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	2553 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	2557 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	3243 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	3335 B (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	3335 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	3340 AK (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	3340 B (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	3340 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	3343 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	3346 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	3348 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	4140 B (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	4140 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	4143 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	4146 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEMEN	4148 K (...00)	FR FMR
 Actros (...00)	DASHBOARD	1831 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1831 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1831 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1831 L nR (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1835 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1835 L nR (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1840 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1840 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1840 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1840 L nR (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1843 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1843 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1843 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1843 L nR (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1846 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1846 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1848 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1848 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1853 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1857 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2031 AK (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2531 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2535 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2540 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2543 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2546 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2548 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2553 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2557 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3243 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3335 B (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3335 K (...00)	MB INS Comb. Instrument

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	DASHBOARD	3340 AK (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3340 B (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3340 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3343 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3346 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3348 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	4140 B (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	4140 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	4143 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	4146 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	4148 K (...00)	MB INS Comb. Instrument
 Actros (...00)	ENGINE MANAGEME	1831 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1831 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1831 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1831 L nR (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1835 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1835 L nR (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1840 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1840 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1840 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1840 L nR (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1843 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1843 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1843 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1843 L nR (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1846 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1846 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1848 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1848 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1853 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1857 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2031 AK (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2531 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2535 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2540 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2543 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2546 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2548 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2553 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2557 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3243 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3335 B (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3335 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3340 AK (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3340 B (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3340 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3343 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3346 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3348 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4140 B (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4140 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4143 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4146 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4148 K (...00)	MB MR PLD (EDC)
 Actros (...00)	GEARBOX MANAGEM	1831 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1831 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1831 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1831 L nR (...00)	MB GS EPS

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS
















Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	GEARBOX MANAGEM	1835 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1835 L nR (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1840 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1840 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1840 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1840 L nR (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1843 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1843 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1843 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1843 L nR (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1846 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1846 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1848 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1848 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1853 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1857 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2031 AK (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2531 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2535 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2540 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2543 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2546 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2548 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2553 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2557 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3243 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3335 B (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3335 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3340 AK (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3340 B (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3340 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3343 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3346 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3348 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4140 B (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4140 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4143 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4146 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4148 K (...00)	MB GS EPS
 Actros (...00)	MAINTENANCE SYST	1831 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1831 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1831 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1831 L nR (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1835 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1835 L nR (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1840 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1840 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1840 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1840 L nR (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1843 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1843 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1843 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1843 L nR (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1846 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1846 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1848 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1848 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1853 L (...00)	MB WS FSS

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	MAINTENANCE SYST	1857 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2031 AK (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2531 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2535 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2540 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2543 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2546 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2548 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2553 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2557 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3243 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3335 B (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3335 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3340 AK (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3340 B (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3340 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3343 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3346 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3348 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4140 B (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4140 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4143 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4146 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4148 K (...00)	MB WS FSS
 Actros (...00)	PRELIMINARY HEATI	1831 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1831 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1831 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1831 L nR (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1835 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1835 L nR (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1840 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1840 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1840 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1840 L nR (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1843 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1843 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1843 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1843 L nR (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1846 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1846 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1848 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1848 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1853 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1857 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2031 AK (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2531 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2535 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2540 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2543 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2546 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2548 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2553 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2557 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3243 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3335 B (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3335 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3340 AK (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3340 B (...00)	MB FLA Termostart.

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	PRELIMINARY HEATI	3340 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3343 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3346 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3348 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4140 B (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4140 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4143 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4146 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4148 K (...00)	MB FLA Termostart.
 Actros (...00)	RATIO SEL. MANAGE	1831 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1831 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1831 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1831 L nR (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1835 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1835 L nR (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1840 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1840 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1840 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1840 L nR (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1843 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1843 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1843 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1843 L nR (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1846 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1846 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1848 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1848 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1853 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1857 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2031 AK (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2531 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2535 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2540 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2543 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2546 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2548 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2553 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2557 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3243 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3335 B (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3335 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3340 AK (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3340 B (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3340 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3343 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3346 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3348 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	4140 B (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	4140 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	4143 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	4146 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	4148 K (...00)	MB AG AGE
 Actros (...00)	SERVICE LIGHT RES	1831 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1831 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1831 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1831 L nR (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1835 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1835 L nR (...00)	MB WS FSS

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	SERVICE LIGHT RES	1840 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1840 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1840 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1840 L nR (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1843 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1843 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1843 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1843 L nR (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1846 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1846 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1848 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1848 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1853 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1857 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2031 AK (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2531 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2535 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2540 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2543 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2546 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2548 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2553 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2557 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3243 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3335 B (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3335 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3340 AK (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3340 B (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3340 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3343 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3346 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3348 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	4140 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	4143 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	4146 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	4148 K (...00)	MB WS FSS
 Actros (...00)	SUSPENSION CONTR	1831 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1831 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1831 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1831 L nR (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1835 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1835 L nR (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1840 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1840 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1840 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1840 L nR (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1843 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1843 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1843 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1843 L nR (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1846 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1846 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1848 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1848 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1853 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1857 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2031 AK (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2531 L (...00)	Wabco NR ECAS

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS

Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	SUSPENSION CONTR	2535 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2540 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2543 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2546 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2548 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2553 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2557 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3243 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3335 B (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3335 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3340 AK (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3340 B (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3340 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3343 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3346 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3348 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4140 B (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4140 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4143 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4146 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4148 K (...00)	Wabco NR ECAS
 Actros (01-02)	ABS	1831 (01-02)	MB ABS
 Actros (01-02)	ABS	1831 K (01-02)	MB ABS
 Actros (01-02)	ABS	1831 L (01-02)	MB ABS
 Actros (01-02)	ABS	1831 L nR (01-02)	MB ABS
 Actros (01-02)	ABS	1835 L (01-02)	MB ABS
 Actros (01-02)	ABS	1835 L nR (01-02)	MB ABS
 Actros (01-02)	ABS	1840 (01-02)	MB ABS
 Actros (01-02)	ABS	1840 K (01-02)	MB ABS
 Actros (01-02)	ABS	1840 L (01-02)	MB ABS
 Actros (01-02)	ABS	1840 L nR (01-02)	MB ABS
 Actros (01-02)	ABS	1843 (01-02)	MB ABS
 Actros (01-02)	ABS	1843 K (01-02)	MB ABS
 Actros (01-02)	ABS	1843 L (01-02)	MB ABS
 Actros (01-02)	ABS	1843 L nR (01-02)	MB ABS
 Actros (01-02)	ABS	1846 (01-02)	MB ABS
 Actros (01-02)	ABS	1846 L (01-02)	MB ABS
 Actros (01-02)	ABS	1848 (01-02)	MB ABS
 Actros (01-02)	ABS	1848 L (01-02)	MB ABS
 Actros (01-02)	ABS	1853 L (01-02)	MB ABS
 Actros (01-02)	ABS	1857 L (01-02)	MB ABS
 Actros (01-02)	ABS	2031 AK (01-02)	MB ABS
 Actros (01-02)	ABS	2531 L (01-02)	MB ABS
 Actros (01-02)	ABS	2535 L (01-02)	MB ABS
 Actros (01-02)	ABS	2540 L (01-02)	MB ABS
 Actros (01-02)	ABS	2543 L (01-02)	MB ABS
 Actros (01-02)	ABS	2546 L (01-02)	MB ABS
 Actros (01-02)	ABS	2548 L (01-02)	MB ABS
 Actros (01-02)	ABS	2553 L (01-02)	MB ABS
 Actros (01-02)	ABS	2557 L (01-02)	MB ABS
 Actros (01-02)	ABS	3243 (01-02)	MB ABS
 Actros (01-02)	ABS	3335 B (01-02)	MB ABS
 Actros (01-02)	ABS	3335 K (01-02)	MB ABS
 Actros (01-02)	ABS	3340 AK (01-02)	MB ABS
 Actros (01-02)	ABS	3340 B (01-02)	MB ABS
 Actros (01-02)	ABS	3340 K (01-02)	MB ABS
 Actros (01-02)	ABS	3343 K (01-02)	MB ABS
 Actros (01-02)	ABS	3346 K (01-02)	MB ABS

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	ABS	3348 K (01-02)	MB ABS
 Actros (01-02)	ABS	4140 B (01-02)	MB ABS
 Actros (01-02)	ABS	4140 K (01-02)	MB ABS
 Actros (01-02)	ABS	4143 K (01-02)	MB ABS
 Actros (01-02)	ABS	4146 K (01-02)	MB ABS
 Actros (01-02)	ABS	4148 K (01-02)	MB ABS
 Actros (01-02)	BRAKE POWER SUPP	1831 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1831 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1831 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1831 L nR (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1835 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1835 L nR (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1840 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1840 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1840 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1840 L nR (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1843 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1843 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1843 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1843 L nR (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1846 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1846 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1848 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1848 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1853 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	1857 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	2031 AK (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	2531 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	2535 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	2540 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	2543 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	2546 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	2548 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	2553 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	2557 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	3243 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	3335 B (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	3335 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	3340 AK (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	3340 B (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	3340 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	3343 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	3346 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	3348 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	4140 B (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	4140 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	4143 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	4146 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUPP	4148 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE SYS. MANAGE	1831 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1831 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1831 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1831 L nR (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1835 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1835 L nR (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1840 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1840 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1840 L (01-02)	MB BS EPB

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	BRAKE SYS. MANAGE	1840 L nR (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1843 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1843 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1843 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1843 L nR (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1846 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1846 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1848 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1848 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1853 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	1857 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	2031 AK (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	2531 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	2535 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	2540 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	2543 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	2546 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	2548 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	2553 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	2557 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	3243 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	3335 B (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	3335 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	3340 AK (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	3340 B (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	3340 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	3343 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	3346 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	3348 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	4140 B (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	4140 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	4143 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	4146 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAGE	4148 K (01-02)	MB BS EPB
 Actros (01-02)	CLIMA	1831 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1831 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	1831 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1831 L nR (01-02)	MB HZR
 Actros (01-02)	CLIMA	1835 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1835 L nR (01-02)	MB HZR
 Actros (01-02)	CLIMA	1840 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1840 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	1840 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1840 L nR (01-02)	MB HZR
 Actros (01-02)	CLIMA	1843 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1843 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	1843 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1843 L nR (01-02)	MB HZR
 Actros (01-02)	CLIMA	1846 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1846 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1848 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1848 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1853 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1857 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2031 AK (01-02)	MB HZR
 Actros (01-02)	CLIMA	2531 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2535 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2540 L (01-02)	MB HZR

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	CLIMA	2543 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2546 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2548 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2553 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2557 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	3243 (01-02)	MB HZR
 Actros (01-02)	CLIMA	3335 B (01-02)	MB HZR
 Actros (01-02)	CLIMA	3335 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	3340 AK (01-02)	MB HZR
 Actros (01-02)	CLIMA	3340 B (01-02)	MB HZR
 Actros (01-02)	CLIMA	3340 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	3343 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	3346 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	3348 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	4140 B (01-02)	MB HZR
 Actros (01-02)	CLIMA	4140 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	4143 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	4146 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	4148 K (01-02)	MB HZR
 Actros (01-02)	CLUTCH ELECTRONI	1831 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1831 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1831 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1831 L nR (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1835 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1835 L nR (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1840 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1840 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1840 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1840 L nR (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1843 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1843 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1843 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1843 L nR (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1846 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1846 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1848 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1848 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1853 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1857 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2031 AK (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2531 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2535 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2540 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2543 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2546 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2548 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2553 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2557 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3243 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3335 B (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3335 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3340 AK (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3340 B (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3340 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3343 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3346 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3348 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	4140 B (01-02)	MB KS MKR

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS


























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	CLUTCH ELECTRONI	4140 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	4143 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	4146 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	4148 K (01-02)	MB KS MKR
 Actros (01-02)	CRUISE MANAGEMEN	1831 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1831 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1831 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1831 L nR (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1835 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1835 L nR (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1840 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1840 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1840 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1840 L nR (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1843 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1843 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1843 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1843 L nR (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1846 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1846 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1848 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1848 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1853 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	1857 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	2031 AK (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	2531 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	2535 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	2540 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	2543 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	2546 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	2548 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	2553 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	2557 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	3243 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	3335 B (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	3335 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	3340 AK (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	3340 B (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	3340 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	3343 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	3346 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	3348 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	4140 B (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	4140 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	4143 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	4146 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEMEN	4148 K (01-02)	FR FMR
 Actros (01-02)	DASHBOARD	1831 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1831 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1831 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1831 L nR (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1835 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1835 L nR (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1840 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1840 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1840 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1840 L nR (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1843 (01-02)	MB INS Comb. Instrument

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	DASHBOARD	1843 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1843 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1843 L nR (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1846 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1846 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1848 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1848 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1853 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1857 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2031 AK (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2531 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2535 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2540 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2543 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2546 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2548 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2553 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2557 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3243 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3335 B (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3335 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3340 AK (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3340 B (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3340 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3343 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3346 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3348 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4140 B (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4140 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4143 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4146 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4148 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	ENGINE MANAGEME	1831 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1831 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1831 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1831 L nR (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1835 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1835 L nR (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1840 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1840 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1840 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1840 L nR (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1843 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1843 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1843 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1843 L nR (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1846 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1846 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1848 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1848 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1853 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1857 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2031 AK (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2531 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2535 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2540 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2543 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2546 L (01-02)	MB MR PLD (EDC)

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





























Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	ENGINE MANAGEME	2548 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2553 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2557 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3243 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3335 B (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3335 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3340 AK (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3340 B (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3340 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3343 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3346 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3348 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	4140 B (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	4140 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	4143 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	4146 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	4148 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	GEARBOX MANAGEM	1831 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1831 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1831 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1831 L nR (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1835 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1835 L nR (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1840 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1840 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1840 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1840 L nR (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1843 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1843 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1843 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1843 L nR (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1846 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1846 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1848 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1848 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1853 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1857 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2031 AK (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2531 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2535 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2540 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2543 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2546 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2548 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2553 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2557 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3243 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3335 B (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3335 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3340 AK (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3340 B (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3340 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3343 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3346 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3348 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	4140 B (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	4140 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	4143 K (01-02)	MB GS EPS

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS


























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	GEARBOX MANAGEM	4146 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	4148 K (01-02)	MB GS EPS
 Actros (01-02)	MAINTENANCE SYST	1831 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1831 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1831 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1831 L nR (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1835 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1835 L nR (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1840 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1840 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1840 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1840 L nR (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1843 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1843 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1843 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1843 L nR (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1846 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1846 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1848 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1848 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1853 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1857 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2031 AK (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2531 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2535 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2540 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2543 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2546 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2548 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2553 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2557 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3243 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3335 B (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3335 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3340 AK (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3340 B (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3340 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3343 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3346 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3348 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4140 B (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4140 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4143 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4146 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4148 K (01-02)	MB WS FSS
 Actros (01-02)	PRELIMINARY HEATI	1831 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1831 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1831 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1831 L nR (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1835 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1835 L nR (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1840 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1840 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1840 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1840 L nR (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1843 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1843 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1843 L (01-02)	MB FLA Termostart.

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	PRELIMINARY HEATI	1843 L nR (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1846 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1846 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1848 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1848 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1853 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1857 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2031 AK (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2531 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2535 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2540 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2543 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2546 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2548 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2553 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2557 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3243 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3335 B (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3335 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3340 AK (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3340 B (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3340 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3343 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3346 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3348 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4140 B (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4140 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4143 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4146 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4148 K (01-02)	MB FLA Termostart.
 Actros (01-02)	RATIO SEL. MANAGE	1831 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1831 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1831 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1831 L nR (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1835 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1835 L nR (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1840 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1840 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1840 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1840 L nR (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1843 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1843 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1843 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1843 L nR (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1846 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1846 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1848 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1848 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1853 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1857 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2031 AK (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2531 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2535 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2540 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2543 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2546 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2548 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2553 L (01-02)	MB AG AGE

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	RATIO SEL. MANAGE	2557 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3243 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3335 B (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3335 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3340 AK (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3340 B (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3340 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3343 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3346 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3348 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4140 B (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4140 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4143 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4146 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4148 K (01-02)	MB AG AGE
 Actros (01-02)	SERVICE LIGHT RES	1831 (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1831 K (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1831 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1831 L nR (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1835 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1835 L nR (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1840 (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1840 K (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1840 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1840 L nR (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1843 (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1843 K (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1843 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1843 L nR (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1846 (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1846 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1848 (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1848 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1853 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1857 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2031 AK (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2531 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2535 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2540 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2543 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2546 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2548 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2553 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2557 L (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3243 (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3335 B (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3335 K (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3340 AK (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3340 B (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3340 K (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3343 K (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3346 K (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3348 K (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	4140 K (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	4143 K (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	4146 K (...00)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	4148 K (...00)	MB WS FSS
 Actros (01-02)	SUSPENSION CONTR	1831 (01-02)	Wabco NR ECAS

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	SUSPENSION CONTR	1831 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1831 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1831 L nR (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1835 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1835 L nR (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1840 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1840 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1840 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1840 L nR (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1843 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1843 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1843 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1843 L nR (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1846 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1846 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1848 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1848 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1853 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1857 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2031 AK (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2531 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2535 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2540 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2543 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2546 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2548 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2553 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2557 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3243 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3335 B (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3335 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3340 AK (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3340 B (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3340 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3343 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3346 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3348 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4140 B (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4140 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4143 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4146 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4148 K (01-02)	Wabco NR ECAS
 Actros MP11 (03-..)	AIRBAG	1832 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	1832 K (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	1836 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	1841 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	1841 K (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	1844 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	1844 K (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	1846 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	1850 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	1854 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	1858 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	2032 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	2041 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	2044 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	2532 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	2536 (03-..)	MB SRS AirBag

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MP11 (03-..)	AIRBAG	2541 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	2544 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	2546 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	2550 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	2554 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	2558 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	4141 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	4144 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	4146 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AIRBAG	4150 (03-..)	MB SRS AirBag
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	1832 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	1832 K (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	1836 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	1841 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	1841 K (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	1844 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	1844 K (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	1846 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	1850 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	1854 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	1858 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	2032 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	2041 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	2044 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	2532 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	2536 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	2541 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	2544 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	2546 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	2550 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	2554 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	2558 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	4141 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	4144 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	4146 (03-..)	MB GS EPS
 Actros MP11 (03-..)	AUTOM. TRANSMISSI	4150 (03-..)	MB GS EPS
 Actros MP11 (03-..)	BRAKE POWER SUPP	1832 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	1832 K (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	1836 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	1841 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	1841 K (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	1844 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	1844 K (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	1846 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	1850 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	1854 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	1858 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	2032 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	2041 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	2044 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	2532 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	2536 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	2541 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	2544 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	2546 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	2550 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	2554 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	2558 (03-..)	MB RS RETARDER

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MP11 (03-..)	BRAKE POWER SUPP	4141 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	4144 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	4146 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE POWER SUPP	4150 (03-..)	MB RS RETARDER
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	1832 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	1832 K (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	1836 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	1841 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	1841 K (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	1844 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	1844 K (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	1846 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	1850 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	1854 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	1858 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	2032 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	2041 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	2044 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	2532 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	2536 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	2541 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	2544 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	2546 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	2550 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	2554 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	2558 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	4141 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	4144 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	4146 (03-..)	MB BS EPB
 Actros MP11 (03-..)	BRAKE SYS. MANAGE	4150 (03-..)	MB BS EPB
 Actros MP11 (03-..)	CHASSIS NETWORK	1832 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	1832 K (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	1836 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	1841 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	1841 K (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	1844 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	1844 K (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	1846 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	1850 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	1854 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	1858 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	2032 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	2041 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	2044 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	2532 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	2536 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	2541 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	2544 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	2546 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	2550 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	2554 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	2558 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	4141 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	4144 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	4146 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHASSIS NETWORK	4150 (03-..)	MB Rear Module
 Actros MP11 (03-..)	CHRONOTACHOGRA	1832 (03-..)	MB TACHOGRAPH
 Actros MP11 (03-..)	CHRONOTACHOGRA	1832 K (03-..)	MB TACHOGRAPH

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MP2 (03-..)	CHRONOTACHOGRA	1836 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	1841 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	1841 K (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	1844 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	1844 K (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	1846 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	1846 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	1850 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	1854 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	1858 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	2032 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	2041 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	2044 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	2532 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	2536 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	2541 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	2544 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	2546 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	2550 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	2554 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	2558 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	4141 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	4144 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	4146 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CHRONOTACHOGRA	4150 (03-..)	MB TACHOGRAPH
 Actros MP2 (03-..)	CRUISE MANAGEMEN	1832 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	1832 K (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	1836 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	1841 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	1841 K (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	1844 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	1844 K (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	1846 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	1850 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	1854 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	1858 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	2032 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	2041 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	2044 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	2532 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	2536 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	2541 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	2544 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	2546 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	2550 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	2554 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	2558 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	4141 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	4144 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	4146 (03-..)	FR FMR
 Actros MP2 (03-..)	CRUISE MANAGEMEN	4150 (03-..)	FR FMR
 Actros MP2 (03-..)	DASHBOARD	1832 (03-..)	MB INS
 Actros MP2 (03-..)	DASHBOARD	1832 K (03-..)	MB INS
 Actros MP2 (03-..)	DASHBOARD	1836 (03-..)	MB INS
 Actros MP2 (03-..)	DASHBOARD	1841 (03-..)	MB INS
 Actros MP2 (03-..)	DASHBOARD	1841 K (03-..)	MB INS
 Actros MP2 (03-..)	DASHBOARD	1844 (03-..)	MB INS
 Actros MP2 (03-..)	DASHBOARD	1844 K (03-..)	MB INS
 Actros MP2 (03-..)	DASHBOARD	1846 (03-..)	MB INS

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MP11 (03-..)	DASHBOARD	1850 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	1854 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	1858 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	2032 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	2041 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	2044 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	2532 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	2536 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	2541 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	2544 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	2546 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	2550 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	2554 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	2558 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	4141 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	4144 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	4146 (03-..)	MB INS
 Actros MP11 (03-..)	DASHBOARD	4150 (03-..)	MB INS
 Actros MP11 (03-..)	ENGINE MANAGEME	1832 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	1832 K (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	1836 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	1841 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	1841 K (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	1844 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	1844 K (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	1846 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	1850 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	1854 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	1858 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	2032 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	2041 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	2044 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	2532 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	2536 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	2541 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	2544 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	2546 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	2550 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	2554 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	2558 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	4141 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	4144 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	4146 (03-..)	MB MR PLD (EDC)
 Actros MP11 (03-..)	ENGINE MANAGEME	4150 (03-..)	MB MR PLD (EDC)
 Atego	ABS	1018 (99-00)	MB ABS
 Atego	ABS	1018 AK (99-00)	MB ABS
 Atego	ABS	1018 L (99-00)	MB ABS
 Atego	ABS	1218 (99-00)	MB ABS
 Atego	ABS	1218 K (99-00)	MB ABS
 Atego	ABS	1218 L (99-00)	MB ABS
 Atego	ABS	1223 (99-00)	MB ABS
 Atego	ABS	1223 L (99-00)	MB ABS
 Atego	ABS	1228 (99-00)	MB ABS
 Atego	ABS	1228 L (99-00)	MB ABS
 Atego	ABS	1518 (99-00)	MB ABS
 Atego	ABS	1518 K (99-00)	MB ABS
 Atego	ABS	1518 L (99-00)	MB ABS
 Atego	ABS	1523 (99-00)	MB ABS

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	ABS	2528 (99-00)	MB ABS
 Atego	ABS	715 (99-00)	MB ABS
 Atego	ABS	715 L (99-00)	MB ABS
 Atego	ABS	815 (99-00)	MB ABS
 Atego	ABS	815 Eco (99-00)	MB ABS
 Atego	ABS	815 L (99-00)	MB ABS
 Atego	ABS	818 (99-00)	MB ABS
 Atego	ABS	818 K (99-00)	MB ABS
 Atego	ABS	818 L (99-00)	MB ABS
 Atego	BRAKE SYS. MANAGE	1018 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	1018 AK (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	1018 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	1218 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	1218 K (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	1218 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	1223 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	1223 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	1228 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	1228 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	1518 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	1518 K (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	1518 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	1523 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	2528 (00-00)	MB BS EPB
 Atego	BRAKE SYS. MANAGE	2528 (98-02)	MB BS EPB
 Atego	CLIMA	1018 (98-02)	MB HZR
 Atego	CLIMA	1018 AK (98-02)	MB HZR
 Atego	CLIMA	1018 L (98-02)	MB HZR
 Atego	CLIMA	1218 (98-02)	MB HZR
 Atego	CLIMA	1218 K (98-02)	MB HZR
 Atego	CLIMA	1218 L (98-02)	MB HZR
 Atego	CLIMA	1223 (98-02)	MB HZR
 Atego	CLIMA	1223 L (98-02)	MB HZR
 Atego	CLIMA	1228 (98-02)	MB HZR
 Atego	CLIMA	1228 L (98-02)	MB HZR
 Atego	CLIMA	1518 (98-02)	MB HZR
 Atego	CLIMA	1518 K (98-02)	MB HZR
 Atego	CLIMA	1518 L (98-02)	MB HZR
 Atego	CLIMA	1523 (98-02)	MB HZR
 Atego	CLIMA	2528 (98-02)	MB HZR
 Atego	CLIMA	715 (98-02)	MB HZR
 Atego	CLIMA	715 L (98-02)	MB HZR
 Atego	CLIMA	815 (98-02)	MB HZR
 Atego	CLIMA	815 Eco (98-02)	MB HZR
 Atego	CLIMA	815 L (98-02)	MB HZR
 Atego	CLIMA	818 (98-02)	MB HZR
 Atego	CLIMA	818 K (98-02)	MB HZR
 Atego	CLIMA	818 L (98-02)	MB HZR
 Atego	CRUISE MANAGEMEN	1018 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1018 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1018 AK (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1018 AK (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1018 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1018 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1218 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1218 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1218 K (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1218 K (98-02)	MB FR FMR

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CRUISE MANAGEMEN	1218 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1218 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1223 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1223 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1223 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1223 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1228 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1228 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1228 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1228 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1518 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1518 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1518 K (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1518 K (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1518 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1518 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1523 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	1523 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	2528 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	2528 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	715 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	715 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	715 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	715 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	815 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	815 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	815 Eco (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	815 Eco (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	815 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	815 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	818 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	818 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	818 K (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	818 K (98-02)	MB FR FMR
 Atego	CRUISE MANAGEMEN	818 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEMEN	818 L (98-02)	MB FR FMR
 Atego	DASHBOARD	1018 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 AK (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 AK (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 L (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 K (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 K (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 L (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1223 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1223 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1223 L (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1223 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1228 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1228 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1228 L (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1228 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1518 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1518 (98-02)	MB INS Comb. Instrument

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	DASHBOARD	1518 K (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1518 K (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1518 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1523 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	2528 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	715 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	715 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	815 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	815 Eco (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	815 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	818 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	818 K (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	818 L (98-02)	MB INS Comb. Instrument
 Atego	ENGINE MANAGEME	1018 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 AK (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 AK (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 K (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 K (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1223 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1223 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1223 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1223 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1228 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1228 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1228 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1228 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 K (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 K (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1523 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1523 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	2528 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	2528 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	715 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	715 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	715 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	715 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	815 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	815 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	815 Eco (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	815 Eco (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	815 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	815 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	818 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	818 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	818 K (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	818 K (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	818 L (00-00)	MB MR PLD

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	ENGINE MANAGEME	818 L (98-02)	MB MR PLD
 Atego	MAINTENANCE SYST	1018 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1018 AK (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1018 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1218 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1218 K (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1218 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1223 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1223 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1228 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1228 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1518 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1518 K (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1518 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1523 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	715 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	715 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	815 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	815 Eco (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	815 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	818 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	818 K (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	818 L (98-02)	MB WS FSS
 Atego	SUSPENSION CONTR	1018 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1018 AK (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1018 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1218 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1218 K (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1218 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1223 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1223 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1228 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1228 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1518 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1518 K (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1518 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1523 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	2528 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	715 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	715 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	815 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	815 Eco (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	815 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	818 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	818 K (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	818 L (98-02)	WABCO NR ECAS
 Axor SKN/C	ENGINE MANAGEME	1835 LS (...02)	MR PLD
 Axor SKN/C	ENGINE MANAGEME	1840 LS (...02)	MR PLD
 Axor SKN/C	ENGINE MANAGEME	1843 LS (...02)	MR PLD
 Axor SKT	CRUISE MANAGEMEN	1835 LS (...02)	FR FMR
 Axor SKT	CRUISE MANAGEMEN	1840 LS (...02)	FR FMR
 Axor SKT	CRUISE MANAGEMEN	1843 LS (...02)	FR FMR
 Axor SKT	ENGINE MANAGEME	1835 LS (...02)	MR PLD
 Axor SKT	ENGINE MANAGEME	1840 LS (...02)	MR PLD
 Axor SKT	ENGINE MANAGEME	1843 LS (...02)	MR PLD
 Econic	ENGINE MANAGEME	1823 LL	MR PLD
 Econic	ENGINE MANAGEME	1828 LL	MR PLD
 Econic	ENGINE MANAGEME	2628 LLc	MR PLD

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Econic	ENGINE MANAGEME	2628 LLp	MR PLD
 Unimog	ENGINE MANAGEME	(..-02)	BOSCH EVE

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



Montenegro

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS + TRACT. CONT	Trailers	Wabco Trailer VCS
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Multicar

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 M26	ENGINE MANAGEME	8140	BOSCH EDC MS 6.3 CR
 M30	ENGINE MANAGEME	8140	BOSCH EDC MS 6.3 CR

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Multitrailer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS + TRACT. CONT	Trailers	Wabco Trailer VCS
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Nardi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS + TRACT. CONT	Trailers	Wabco Trailer VCS
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Nissan

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Pick-Up	ENGINE MANAGEME	2.4 88kW (01-..)	EOBD
 Pick-Up	ENGINE MANAGEME	2.5 D (01-..)	EOBD
 Pick-Up	ENGINE MANAGEME	2.5 TD (01-..)	EOBD
 Primastar	ENGINE MANAGEME	1.9 dCi F9Q	BOSCH EDC 15 C3 Common Rail

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS














O.M.E.P.S.

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS + TRACT. CONT	Trailers	Wabco Trailer VCS
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS


Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Combo	ABS		BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.3 CDTI Z13DT (...03)	BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.3 CDTI Z13DT (04-..)	BOSCH ABS 8
 Combo	AIRBAG	1.3 CDTI Z13DT	SIEMENS AirBag SAB8x
 Combo	AIRBAG	1.3 CDTI Z13DT (01-..)	TEMIC AirBag 07
 Combo	CHASSIS NETWORK	1.3 CDTI Z13DT	SIEMENS Body computer
 Combo	DASHBOARD	1.3 CDTI Z13DT (02-..)	SIEMENS
 Combo	ELECTRIC STEERING	1.3 CDTI Z13DT	
 Combo	ENGINE MANAGEME	1.3 CDTI Z13DT (03-..)	MARELLI 6JF
 Combo	ENGINE MANAGEME	1.4 X14SZ (97-00)	GM Multec S (F)
 Combo	IMMOBILIZER	1.3 CDTI Z13DT	SIEMENS
 Vivaro	AIRBAG	(02-..)	SAGEM - Autoliv ACU xx
 Vivaro	ENGINE MANAGEME	1.9 dCi 100 Cv F9Q U7	BOSCH EDC 15 C3 Common Rail

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS



























































Paganini

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS








Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Expert	ABS	1.9 TD DHX	BOSCH ABS ABR 5.3
 Expert	ABS	2.0 HDI RHZ	BOSCH ABS ABR 5.3
 Expert	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Expert	DIESEL MANAGEMEN	1.9 TD DHX	BOSCH AS3 VP20
 Expert	ENGINE MANAGEME	2.0 HDI RHT	BOSCH EDC 15 C2 Common Rail
 Expert	ENGINE MANAGEME	2.0 HDI RHZ (...00)	BOSCH EDC 15 C2 Common Rail
 Partner	ABS	1.1 HDY	BOSCH ABS ABR 5.3
 Partner	ABS	1.1 HDZ	BOSCH ABS ABR 5.3
 Partner	ABS	1.4 KFX	BOSCH ABS ABR 5.3
 Partner	ABS	1.9 D WJY	BOSCH ABS ABR 5.3
 Partner	ABS	2.0 HDI RHY	BOSCH ABS ABR 5.3
 Partner	ABS	2.0 HDI RHZ	BOSCH ABS ABR 5.3
 Partner	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Partner	ENGINE MANAGEME	1.1 HDY	BOSCH MonoMotronic MA3.1
 Partner	ENGINE MANAGEME	1.1 HDZ	BOSCH MonoMotronic MA3.1
 Partner	ENGINE MANAGEME	1.4 KFX	MARELLI MM 1AP.81
 Partner	ENGINE MANAGEME	1.4 KFX	SAGEM SL 96
 Partner	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS Diesel SID 801
 Partner	ENGINE MANAGEME	2.0 HDI RHY (...00)	BOSCH EDC 15 C2 Common Rail
 Partner	ENGINE MANAGEME	2.0 HDI RHZ (...00)	BOSCH EDC 15 C2 Common Rail
 Ranch	ABS	1.1 HDY	BOSCH ABS ABR 5.3
 Ranch	ABS	1.1 HDZ	BOSCH ABS ABR 5.3
 Ranch	ABS	1.4 KFX	BOSCH ABS ABR 5.3
 Ranch	ABS	1.9 D WJY	BOSCH ABS ABR 5.3
 Ranch	ABS	2.0 HDI RHY	BOSCH ABS ABR 5.3
 Ranch	ABS	2.0 HDI RHZ	BOSCH ABS ABR 5.3
 Ranch	AIRBAG	1.1 HDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.1 HDZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.4 KFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.9 D WJY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	2.0 HDI RHY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	CHASSIS NETWORK	1.1 (...01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	1.4 (...01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	1.9 D (...01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	2.0 HDI (...01)	VALEO Body Computer
 Ranch	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Ranch	ENGINE MANAGEME	1.1 HDY	BOSCH MonoMotronic MA3.1
 Ranch	ENGINE MANAGEME	1.1 HDZ	BOSCH MonoMotronic MA3.1
 Ranch	ENGINE MANAGEME	1.4 KFW	SAGEM S2000
 Ranch	ENGINE MANAGEME	1.4 KFX	MARELLI MM 1AP.40
 Ranch	ENGINE MANAGEME	1.6 16v NFU	BOSCH Motronic ME7.4.4
 Ranch	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS Diesel SID 801
 Ranch	ENGINE MANAGEME	2.0 HDI RHY (...00)	BOSCH EDC 15 C2 Common Rail
 Ranch	ENGINE MANAGEME	2.0 HDI RHZ (...99)	BOSCH EDC 15 C2 Common Rail
 Ranch	RADIO / CD	1.1	CLARION
 Ranch	RADIO / CD	1.1	PHILIPS
 Ranch	RADIO / CD	1.1	VDO
 Ranch	RADIO / CD	1.4	CLARION
 Ranch	RADIO / CD	1.4	PHILIPS
 Ranch	RADIO / CD	1.4	VDO
 Ranch	RADIO / CD	1.9 D	CLARION
 Ranch	RADIO / CD	1.9 D	PHILIPS
 Ranch	RADIO / CD	1.9 D	VDO
 Ranch	RADIO / CD	2.0 HDI	CLARION
 Ranch	RADIO / CD	2.0 HDI	PHILIPS
 Ranch	RADIO / CD	2.0 HDI	VDO
 Ranch	SERVICE LIGHT RES	(98-00)	VDO
 Ranch	SWITCHLIGHT MODU	1.1	EATON

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ranch	SWITCHLIGHT MODU	1.4	EATON
 Ranch	SWITCHLIGHT MODU	1.9 D	EATON
 Ranch	SWITCHLIGHT MODU	2.0 HDI	EATON
 Ranch	VISUAL./TELEMATICS	1.1	SAGEM
 Ranch	VISUAL./TELEMATICS	1.4	SAGEM
 Ranch	VISUAL./TELEMATICS	1.9 D	SAGEM
 Ranch	VISUAL./TELEMATICS	2.0 HDI	SAGEM

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





























































Piacenza

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





























































Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Express	AIRBAG		SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG		SIEMENS - Autoliv AirBag EC5
 Express	ENGINE MANAGEME	1.2 C3G - 702	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 C3G - 710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 C3G - 710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 C3G - 710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 C3G - 710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 C3G - 710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 C3G - 710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.4 C3J - 702	SIEMENS RENIX Monopoint
 Express	ENGINE MANAGEME	1.4 C3J - 760	SIEMENS RENIX Monopoint
 Express	ENGINE MANAGEME	1.4 C3J - 762	SIEMENS RENIX Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 720	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 720	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 720	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 720	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 720	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 724	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 724	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 724	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 724	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 724	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 724	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 728	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 728	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 728	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 728	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 728	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 728	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 770	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 773	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 773	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 773	SIEMENS BOSCH Monopoint
 Kangoo	ABS	1.2	BOSCH ABS 5.3
 Kangoo	ABS	1.2	BOSCH ABS 5.3 T
 Kangoo	ABS	1.2 16v	BOSCH ABS 5.3
 Kangoo	ABS	1.2 16v	BOSCH ABS 5.3 T
 Kangoo	ABS	1.4	BOSCH ABS 5.3
 Kangoo	ABS	1.4	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 65cv	BOSCH ABS 5.3
 Kangoo	ABS	1.5 dCi 65cv	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 80cv	BOSCH ABS 5.3
 Kangoo	ABS	1.5 dCi 80cv	BOSCH ABS 5.3 T
 Kangoo	ABS	1.6 16v	BOSCH ABS 5.3
 Kangoo	ABS	1.6 16v	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 D	BOSCH ABS 5.3
 Kangoo	ABS	1.9 D	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 dCi	BOSCH ABS 5.3
 Kangoo	ABS	1.9 dCi	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 dTi	BOSCH ABS 5.3
 Kangoo	ABS	1.9 dTi	BOSCH ABS 5.3 T
 Kangoo	AIRBAG	1.2	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.2	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.2	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.2 16v	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.2 16v	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.2 16v	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.4	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.4	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.4	SIEMENS - Autoliv AirBag EC5

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS






Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	AIRBAG	1.5 dCi 65cv	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 65cv	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.5 dCi 65cv	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.5 dCi 80cv	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 80cv	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.5 dCi 80cv	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.6 16v	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.6 16v	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.6 16v	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 D	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 D	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 D	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 dCi	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 dCi	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 dCi	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 dTi	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 dTi	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 dTi	SIEMENS - Autoliv AirBag EC5
 Kangoo	DIESEL MANAGEMEN	1.9 D F8Q	SIEMENS Diesel DCU3R
 Kangoo	DIESEL MANAGEMEN	1.9 D F8Q (55Kw) (...99)	LUCAS Diesel DPCN1
 Kangoo	DIESEL MANAGEMEN	1.9 dTi F9Q	BOSCH MSA 15
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - G7	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.4 (01-..)	EOBD
 Kangoo	ENGINE MANAGEME	1.4 16v K4J	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.4 E7J	SIEMENS FENIX 5
 Kangoo	ENGINE MANAGEME	1.4 E7J	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.5 dCi 65cv K9K	DELPHI LUCAS LVCR Common Rail
 Kangoo	ENGINE MANAGEME	1.6 16v K4M	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.9 D F8Q	LUCAS Diesel DCU3R
 Kangoo	ENGINE MANAGEME	1.9 dCi F9Q - 740 (...00)	BOSCH EDC 15 C3 Common Rail
 Kangoo	IMMOBILIZER	1.2	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.2 16v	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.4	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 65cv	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 80cv	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.6 16v	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 D	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 dCi	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 dTi	Immobilizer Body Computer
 Master	ABS		TEVES ABS MK20T
 Master	ABS	(01-..)	TEVES ABS MK60
 Master	AIRBAG		SAGEM - Autoliv ACU 3
 Master	AIRBAG		SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG		SIEMENS - Autoliv AirBag EC5
 Master	ENGINE MANAGEME	2.2 16v dCi G9T D7 (01-..)	BOSCH EDC 15 C3 Common Rail
 Master	ENGINE MANAGEME	2.2 J7T - 782	SIEMENS Multipoint
 Master	ENGINE MANAGEME	2.2 J7T - 788	SIEMENS Multipoint
 Megane	DIESEL MANAGEMEN	1.9 D F8Q	SIEMENS Diesel DCU3R
 Trafic	AIRBAG		SIEMENS - Autoliv AirBag AC4
 Trafic	AIRBAG		SIEMENS - Autoliv AirBag EC5

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS


























































Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trafic	AIRBAG	1.9 dCi (...-02)	SAGEM - Autoliv ACU xx
 Trafic	ENGINE MANAGEME	1.9 dCi F9Q	BOSCH EDC 15 C3 Common Rail
 Trafic	ENGINE MANAGEME	2.2 J7T	SIEMENS BENDIX-FENIX Multipoint
 Trafic	ENGINE MANAGEME	2.2 J7T	SIEMENS BENDIX-FENIX Multipoint
 Trafic	ENGINE MANAGEME	2.2 J7T	SIEMENS BENDIX-FENIX Multipoint

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS










































Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kerax	ABS	270	WABCO ABS D-E
 Kerax	ABS	320	WABCO ABS D-E
 Kerax	ABS	370	WABCO ABS D-E
 Kerax	ABS	420	WABCO ABS D-E
 Kerax	AUTOM. TRANSMISSI	270	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	320	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	370	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	420	ZF ASTRONIC
 Kerax	BRAKE SYS. MANAGE	270	WABCO EBS
 Kerax	BRAKE SYS. MANAGE	320	WABCO EBS
 Kerax	BRAKE SYS. MANAGE	370	WABCO EBS
 Kerax	BRAKE SYS. MANAGE	420	WABCO EBS
 Kerax	ENGINE MANAGEME	250	DENSO ITC
 Kerax	ENGINE MANAGEME	260	DENSO ITC
 Kerax	ENGINE MANAGEME	270	dCi EURO 3
 Kerax	ENGINE MANAGEME	320	dCi EURO 3
 Kerax	ENGINE MANAGEME	340	DENSO ITC
 Kerax	ENGINE MANAGEME	370	dCi EURO 3
 Kerax	ENGINE MANAGEME	385	DENSO ITC
 Kerax	ENGINE MANAGEME	400	DENSO ITC
 Kerax	ENGINE MANAGEME	420	dCi EURO 3
 Magnum	ENGINE MANAGEME	440	dCi EURO 3
 Magnum	ENGINE MANAGEME	480	dCi EURO 3
 Magnum	ENGINE MANAGEME	420	DENSO ITC
 Maxter	ENGINE MANAGEME	300	DENSO ITC
 Maxter	ENGINE MANAGEME	340	DENSO ITC
 Maxter	ENGINE MANAGEME	385	DENSO ITC
 Maxter	ENGINE MANAGEME	400	DENSO ITC
 Midliner M	ENGINE MANAGEME	250	DENSO ITC
 Midlum	ABS	150	WABCO ABS D-E
 Midlum	ABS	180	WABCO ABS D-E
 Midlum	ABS	220	WABCO ABS D-E
 Midlum	ABS	270	WABCO ABS D-E
 Midlum	DASHBOARD	150	AFFI COMBINSTRUM 2000
 Midlum	DASHBOARD	180	AFFI COMBINSTRUM 2000
 Midlum	DASHBOARD	220	AFFI COMBINSTRUM 2000
 Midlum	DASHBOARD	270	AFFI COMBINSTRUM 2000
 Midlum	ENGINE MANAGEME	150	dCi EURO 3
 Midlum	ENGINE MANAGEME	180	dCi EURO 3
 Midlum	ENGINE MANAGEME	220	dCi EURO 3
 Midlum	ENGINE MANAGEME	270	dCi EURO 3
 Midlum	SUSPENSION CONTR	150	Wabco
 Midlum	SUSPENSION CONTR	180	Wabco
 Midlum	SUSPENSION CONTR	220	Wabco
 Midlum	SUSPENSION CONTR	270	Wabco
 Premium	ABS	220	WABCO ABS D-E
 Premium	ABS	260	BOSCH ABS I8
 Premium	ABS	270	WABCO ABS D-E
 Premium	ABS	300	BOSCH ABS I8
 Premium	ABS	320	WABCO ABS D-E
 Premium	ABS	340	BOSCH ABS I8
 Premium	ABS	370	WABCO ABS D-E
 Premium	ABS	385	BOSCH ABS I8
 Premium	ABS	420	WABCO ABS D-E
 Premium	AUTOM. TRANSMISSI	220	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	270	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	320	ZF ASTRONIC

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS
















































Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium	AUTOM. TRANSMISSI	370	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	420	ZF ASTRONIC
 Premium	BRAKE SYS. MANAGE	220	WABCO EBS
 Premium	BRAKE SYS. MANAGE	270	WABCO EBS
 Premium	BRAKE SYS. MANAGE	320	WABCO EBS
 Premium	BRAKE SYS. MANAGE	370	WABCO EBS
 Premium	BRAKE SYS. MANAGE	420	WABCO EBS
 Premium	CHASSIS NETWORK	220	VECU 3 Body Computer
 Premium	CHASSIS NETWORK	270	VECU 3 Body Computer
 Premium	CHASSIS NETWORK	320	VECU 3 Body Computer
 Premium	CHASSIS NETWORK	370	VECU 3 Body Computer
 Premium	CHASSIS NETWORK	420	VECU 3 Body Computer
 Premium	DASHBOARD	220	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	270	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	320	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	370	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	420	AFFI COMBINSTRUM 2000
 Premium	ENGINE MANAGEME	220	dCi EURO 3
 Premium	ENGINE MANAGEME	250	DENSO ITC
 Premium	ENGINE MANAGEME	270	dCi EURO 3
 Premium	ENGINE MANAGEME	300	DENSO ITC
 Premium	ENGINE MANAGEME	320	dCi EURO 3
 Premium	ENGINE MANAGEME	340	DENSO ITC
 Premium	ENGINE MANAGEME	370	dCi EURO 3
 Premium	ENGINE MANAGEME	385	DENSO ITC
 Premium	ENGINE MANAGEME	400	DENSO ITC
 Premium	ENGINE MANAGEME	420	dCi EURO 3
 Premium	SPEED LIMITER	260	ACTIA LIVASR
 Premium	SPEED LIMITER	300	ACTIA LIVASR
 Premium	SPEED LIMITER	340	ACTIA LIVASR
 Premium	SPEED LIMITER	385	ACTIA LIVASR
 Premium	SUSPENSION CONTR	220	Wabco
 Premium	SUSPENSION CONTR	260	WABCO ECAS JED
 Premium	SUSPENSION CONTR	270	Wabco
 Premium	SUSPENSION CONTR	300	WABCO ECAS JED
 Premium	SUSPENSION CONTR	320	Wabco
 Premium	SUSPENSION CONTR	340	WABCO ECAS JED
 Premium	SUSPENSION CONTR	370	Wabco
 Premium	SUSPENSION CONTR	385	WABCO ECAS JED
 Premium	SUSPENSION CONTR	420	Wabco
 Sisu	ENGINE MANAGEME	480	dCi EURO 3

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS











Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 L124	ABS	420 (...99)	BOSCH ABS I8
 L144	ABS	530 (...99)	BOSCH ABS I8
 L164	ABS	480 (...99)	BOSCH ABS I8
 P113	ABS	400 (...99)	BOSCH ABS I8
 P113	ENGINE MANAGEME	400 (92-97)	BOSCH EDC M7
 P114	ABS	340 (...99)	BOSCH ABS I8
 P114	ABS	380 (...99)	BOSCH ABS I8
 P114	ENGINE MANAGEME	340 (96-...)	BOSCH EDC
 P114	ENGINE MANAGEME	380 (96-...)	BOSCH EDC
 P124	ABS	420 (...99)	BOSCH ABS I8
 P124	ENGINE MANAGEME	420 (95-...)	BOSCH EDC
 P164	ABS	580 (...99)	BOSCH ABS I8
 P94	ABS	230 (...99)	BOSCH ABS I8
 P94	ABS	260 (...99)	BOSCH ABS I8
 P94	ABS	300 (...99)	BOSCH ABS I8
 R113	ABS	380 (...99)	BOSCH ABS I8
 R113	ENGINE MANAGEME	380 (91-97)	BOSCH EDC M7
 R114	ABS	340 (...99)	BOSCH ABS I8
 R114	ABS	380 (...99)	BOSCH ABS I8
 R114	ENGINE MANAGEME	340 (96-...)	BOSCH EDC
 R114	ENGINE MANAGEME	380 (96-...)	BOSCH EDC
 R124	ABS	420 (...99)	BOSCH ABS I8
 R124	ABS	440 (...99)	BOSCH ABS I8
 R124	ABS	470 (...99)	BOSCH ABS I8
 R124	ENGINE MANAGEME	420 (95-...)	BOSCH EDC
 R143	ABS	470 (...99)	BOSCH ABS I8
 R143	ABS	500 (...99)	BOSCH ABS I8
 R143	ENGINE MANAGEME	470 (88-91)	BOSCH EDC M7
 R143	ENGINE MANAGEME	500 (91-96)	BOSCH EDC M7
 R144	ABS	530 (...99)	BOSCH ABS I8
 R144	ENGINE MANAGEME	530 (96-01)	BOSCH EDC
 R164	ABS	480 (...99)	BOSCH ABS I8
 R164	ABS	580 (...99)	BOSCH ABS I8
 T114	ABS	380 (...99)	BOSCH ABS I8
 T114	ENGINE MANAGEME	340 (96-...)	BOSCH EDC
 T114	ENGINE MANAGEME	380 (96-...)	BOSCH EDC
 T124	ABS	400 (...99)	BOSCH ABS I8
 T124	ABS	420 (...99)	BOSCH ABS I8
 T124	ENGINE MANAGEME	400 (98-...)	BOSCH EDC
 T124	ENGINE MANAGEME	420 (95-...)	BOSCH EDC
 T124	ENGINE MANAGEME	420 (96-...)	BOSCH EDC
 T143	ABS	500 (...99)	BOSCH ABS I8
 T143	ENGINE MANAGEME	500 (88-96)	BOSCH EDC M7
 T144	ABS	500 (...99)	BOSCH ABS I8
 T144	ENGINE MANAGEME	530 (96-01)	BOSCH EDC
 T164	ABS	480 (...99)	BOSCH ABS I8
 T164	ABS	580 (...99)	BOSCH ABS I8

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Scania Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 BN113	ENGINE MANAGEME	180 (90-98)	BOSCH EDC M7
 BN113	ENGINE MANAGEME	260 (90-98)	BOSCH EDC M7
 K113	ENGINE MANAGEME	380 (90-..)	BOSCH EDC M7
 K124	ENGINE MANAGEME	360 (97-..)	BOSCH EDC M7
 K124	ENGINE MANAGEME	420 (97-..)	BOSCH EDC
 K124	ENGINE MANAGEME	420 (97-..)	BOSCH EDC Lucas
 K124	ENGINE MANAGEME	420 (97-..)	BOSCH EDC M7
 L113	ENGINE MANAGEME	(93-98)	BOSCH EDC M7
 L113	ENGINE MANAGEME	250 (92-98)	BOSCH EDC M7
 N113	ENGINE MANAGEME	250 (91-98)	BOSCH EDC M7

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Schmitz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS
















Schwartz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS + TRACT. CONT	Trailers	Wabco Trailer VCS
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS















Setra

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Top Class	BRAKE SYS. MANAGE	S 411 HD	BS EBS ZF
 Top Class	BRAKE SYS. MANAGE	S 415 HD	BS EBS ZF
 Top Class	BRAKE SYS. MANAGE	S 415 HDH	BS EBS ZF
 Top Class	BRAKE SYS. MANAGE	S 417 HDH	BS EBS ZF
 Top Class	BRAKE SYS. MANAGE	S 431 DT	BS EBS ZF
 Top Class	CRUISE MANAGEMEN	S 411 HD	FR FMR
 Top Class	CRUISE MANAGEMEN	S 415 HD	FR FMR
 Top Class	CRUISE MANAGEMEN	S 415 HDH	FR FMR
 Top Class	CRUISE MANAGEMEN	S 417 HDH	FR FMR
 Top Class	CRUISE MANAGEMEN	S 431 DT	FR FMR
 Top Class	ENGINE MANAGEME	S 411 HD	MR PLD
 Top Class	ENGINE MANAGEME	S 415 HD	MR PLD
 Top Class	ENGINE MANAGEME	S 415 HDH	MR PLD
 Top Class	ENGINE MANAGEME	S 417 HDH	MR PLD
 Top Class	ENGINE MANAGEME	S 431 DT	MR PLD

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS

Skoda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Pick-up	ABS	(..-03)	
 Pick-up	AIRBAG	(..-03)	
 Pick-up	AUX. HEATING	(..-00)	
 Pick-up	CENTRAL LOCKING	(..-00)	
 Pick-up	CLUTCH ELECTRONI	(..-00)	
 Pick-up	DASHBOARD	(..-00)	
 Pick-up	DRIVER SEAT CONTR	(..-00)	
 Pick-up	ENGINE MANAGEME	(..-03)	
 Pick-up	ENGINE MANAGEME	(..-03)	
 Pick-up	ENGINE MANAGEME	(..-03)	
 Pick-up	IMMOBILIZER	(..-00)	
 Pick-up	PARKING HELP	(..-00)	
 Pick-up	RADIO / CD	(..-03)	
 Pick-up	SUSPENSION CONTR	(..-00)	

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS




Tecnokar

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS















Toyota

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 HiAce	ENGINE MANAGEME	2.5 D-4D 2KD-FTV (01-..)	EOBD
 HiAce	ENGINE MANAGEME	2.7 3RZ-FE (01-..)	EOBD
 HiLux	ENGINE MANAGEME	2.5 D-4D 2KD-FTV (01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 F10	ENGINE MANAGEME	290 (91-94)	BOSCH EDC M7
 F12	ENGINE MANAGEME	370 (90-94)	BOSCH EDC M7
 F12	ENGINE MANAGEME	390 (87-94)	BOSCH EDC M7
 F16	ENGINE MANAGEME	370 (91-94)	BOSCH EDC M7
 FH12	ENGINE MANAGEME	340 (93-98)	BOSCH EDC
 FH12	ENGINE MANAGEME	380 (93-98)	BOSCH EDC
 FH12	ENGINE MANAGEME	420 (93-98)	BOSCH EDC
 FH16	ENGINE MANAGEME	470 (93-98)	BOSCH EDC M7
 FH16	ENGINE MANAGEME	520 (93-98)	BOSCH EDC M7
 FL10	ENGINE MANAGEME	286 (92-94)	BOSCH EDC M7
 FL12	ENGINE MANAGEME	380 (95-...)	BOSCH EDC
 FL12	ENGINE MANAGEME	420 (95-...)	BOSCH EDC
 NL12	ENGINE MANAGEME	360 (96-...)	BOSCH EDC M7
 NL12	ENGINE MANAGEME	400 (96-...)	BOSCH EDC M7

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS


















































Volvo Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 B12	ENGINE MANAGEME	340 (95-...)	BOSCH EDC
 B12	ENGINE MANAGEME	380 (95-...)	BOSCH EDC
 B12	ENGINE MANAGEME	400 (92-95)	BOSCH EDC M7
 B12	ENGINE MANAGEME	420 (95-...)	BOSCH EDC

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS





VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Caddy	ABS	(04-..)	
 Caddy	AIRBAG	(..-03)	
 Caddy	AIRBAG	(04-..)	
 Caddy	ENGINE MANAGEME	(..-03)	
 Caddy	ENGINE MANAGEME	(..-03)	
 Caddy	ENGINE MANAGEME	(..-03)	
 Caddy	ENGINE MANAGEME	1.9 TDI (04-..)	
 Caddy	ENGINE MANAGEME	(04-..)	
 Caddy	IMMOBILIZER	(..-00)	
 Caddy	SERVICE LIGHT RES	(93-96)	
 Caddy	SERVICE LIGHT RES	(98-98)	
 Caravelle	ABS	(..-6/98)	
 Caravelle	AIRBAG	(..-6/98)	
 Caravelle	AUTOM. TRANSMISSI	(..-6/98)	
 Caravelle	CENTRAL LOCKING	(..-6/98)	
 Caravelle	CLIMA	(..-6/98)	
 Caravelle	CONV. TOP/SUNROO	(..-6/98)	
 Caravelle	ENGINE MANAGEME	(..-6/98)	
 Caravelle	ENGINE MANAGEME	(..-6/98)	
 Caravelle	ENGINE MANAGEME	(..-6/98)	
 Caravelle	IMMOBILIZER	(..-6/98)	
 Caravelle	SERVICE LIGHT RES	(93-96)	
 Caravelle	SERVICE LIGHT RES	(98-98)	
 LT 98	ENGINE MANAGEME	(..-01)	
 LT 98	IMMOBILIZER	(..-01)	
 LT 98	SERVICE LIGHT RES	(98-98)	
 LT	ABS	(..-6/96)	
 LT	ENGINE MANAGEME	(..-6/96)	
 LT	ENGINE MANAGEME	(..-6/96)	
 LT	ENGINE MANAGEME	(..-6/96)	
 LT	IMMOBILIZER	(..-6/96)	
 LT	SERVICE LIGHT RES	(93-96)	
 Taro	AIRBAG	(..-6/98)	
 Taro	ENGINE MANAGEME	(..-6/98)	
 Taro	ENGINE MANAGEME	(..-6/98)	
 Taro	ENGINE MANAGEME	(..-6/98)	
 Taro	IMMOBILIZER	(..-6/98)	
 Taro	SERVICE LIGHT RES	(93-96)	
 Taro	SERVICE LIGHT RES	(98-98)	
 Transporter	ABS	(..-6/98)	
 Transporter	AIRBAG	(..-6/98)	
 Transporter	CLIMA	(..-6/98)	
 Transporter	ENGINE MANAGEME	(..-6/98)	
 Transporter	ENGINE MANAGEME	(..-6/98)	
 Transporter	ENGINE MANAGEME	(..-6/98)	
 Transporter	IMMOBILIZER	(..-6/98)	
 Transporter	SERVICE LIGHT RES	(93-96)	
 Transporter	SERVICE LIGHT RES	(98-98)	
 Transporter	SERVICE LIGHT RES	(99-..)	

Systems supported by ECUreader / ECUdecoder (up to V3,70)

TRUCKS

Zorzi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAGE	Trailers	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAGE	Trailers	Wabco Trailers EBS kw2000